

WPILibC++

Version 1.0

Generated by Doxygen 1.5.7.1

Sat Dec 27 17:14:39 2008

Contents

1	Todo List	1
2	Bug List	3
3	Class Index	5
3.1	Class Hierarchy	5
4	Class Index	7
4.1	Class List	7
5	Class Documentation	9
5.1	Accelerometer Class Reference	9
5.1.1	Detailed Description	9
5.1.2	Constructor & Destructor Documentation	9
5.1.2.1	Accelerometer	9
5.1.2.2	Accelerometer	9
5.1.2.3	Accelerometer	10
5.1.2.4	~Accelerometer	10
5.1.3	Member Function Documentation	10
5.1.3.1	GetAcceleration	10
5.1.3.2	SetSensitivity	10
5.1.3.3	SetZero	10
5.2	AnalogChannel Class Reference	11
5.2.1	Detailed Description	11
5.2.2	Constructor & Destructor Documentation	12
5.2.2.1	AnalogChannel	12
5.2.2.2	AnalogChannel	12
5.2.2.3	~AnalogChannel	12
5.2.3	Member Function Documentation	12
5.2.3.1	GetAccumulatorCount	12

5.2.3.2	GetAccumulatorOutput	12
5.2.3.3	GetAccumulatorValue	13
5.2.3.4	GetAverageBits	13
5.2.3.5	GetAverageValue	13
5.2.3.6	GetAverageVoltage	13
5.2.3.7	GetChannel	13
5.2.3.8	GetLSBWeight	14
5.2.3.9	GetModule	14
5.2.3.10	GetOffset	14
5.2.3.11	GetOversampleBits	14
5.2.3.12	GetSlot	14
5.2.3.13	GetValue	15
5.2.3.14	GetVoltage	15
5.2.3.15	InitAccumulator	15
5.2.3.16	IsAccumulatorChannel	15
5.2.3.17	ResetAccumulator	15
5.2.3.18	SetAccumulatorCenter	15
5.2.3.19	SetAccumulatorDeadband	15
5.2.3.20	SetAccumulatorInitialValue	16
5.2.3.21	SetAverageBits	16
5.2.3.22	SetOversampleBits	16
5.3	AnalogModule Class Reference	17
5.3.1	Detailed Description	17
5.3.2	Constructor & Destructor Documentation	18
5.3.2.1	AnalogModule	18
5.3.2.2	~AnalogModule	18
5.3.3	Member Function Documentation	18
5.3.3.1	GetAverageBits	18
5.3.3.2	GetAverageValue	18
5.3.3.3	GetAverageVoltage	19
5.3.3.4	GetInstance	19
5.3.3.5	GetLSBWeight	19
5.3.3.6	GetOffset	19
5.3.3.7	GetOversampleBits	20
5.3.3.8	GetSampleRate	20
5.3.3.9	GetValue	20

5.3.3.10	GetVoltage	20
5.3.3.11	SetAverageBits	21
5.3.3.12	SetOversampleBits	21
5.3.3.13	SetSampleRate	21
5.3.3.14	SlotToIndex	21
5.3.3.15	VoltsToValue	22
5.4	AnalogTriggerOutput Class Reference	23
5.4.1	Detailed Description	23
5.4.2	Constructor & Destructor Documentation	23
5.4.2.1	AnalogTriggerOutput	23
5.4.3	Member Function Documentation	24
5.4.3.1	Get	24
5.4.3.2	GetAnalogTriggerForRouting	24
5.4.3.3	GetChannelForRouting	24
5.4.3.4	GetModuleForRouting	24
5.4.3.5	RequestInterrupts	24
5.4.3.6	RequestInterrupts	25
5.5	ColorReport_struct Struct Reference	26
5.5.1	Detailed Description	26
5.6	Compressor Class Reference	27
5.6.1	Detailed Description	27
5.6.2	Constructor & Destructor Documentation	27
5.6.2.1	Compressor	27
5.6.2.2	Compressor	27
5.6.2.3	~Compressor	28
5.6.3	Member Function Documentation	28
5.6.3.1	Enabled	28
5.6.3.2	GetPressureSwitchValue	28
5.6.3.3	SetRelayValue	28
5.6.3.4	Start	28
5.6.3.5	Stop	28
5.7	Counter Class Reference	29
5.7.1	Detailed Description	29
5.7.2	Constructor & Destructor Documentation	30
5.7.2.1	Counter	30
5.7.2.2	Counter	30

5.7.2.3	Counter	30
5.7.2.4	Counter	30
5.7.2.5	Counter	30
5.7.2.6	~Counter	30
5.7.3	Member Function Documentation	30
5.7.3.1	ClearDownSource	30
5.7.3.2	ClearUpSource	30
5.7.3.3	Get	31
5.7.3.4	GetDirection	31
5.7.3.5	GetStopped	31
5.7.3.6	Reset	31
5.7.3.7	SetDownSource	31
5.7.3.8	SetDownSource	31
5.7.3.9	SetDownSource	31
5.7.3.10	SetDownSource	32
5.7.3.11	SetDownSource	32
5.7.3.12	SetDownSource	32
5.7.3.13	SetDownSourceEdge	32
5.7.3.14	SetExternalDirectionMode	32
5.7.3.15	SetMaxPeriod	32
5.7.3.16	SetPulseLengthMode	32
5.7.3.17	SetSemiPeriodMode	33
5.7.3.18	SetUpdateWhenEmpty	33
5.7.3.19	SetUpDownCounterMode	33
5.7.3.20	SetUpSource	33
5.7.3.21	SetUpSource	33
5.7.3.22	SetUpSource	33
5.7.3.23	SetUpSource	33
5.7.3.24	SetUpSource	34
5.7.3.25	SetUpSource	34
5.7.3.26	SetUpSourceEdge	34
5.7.3.27	Start	34
5.7.3.28	Stop	34
5.8	CounterBase Class Reference	35
5.8.1	Detailed Description	35
5.9	Dashboard Class Reference	36

5.9.1	Detailed Description	36
5.9.2	Member Function Documentation	36
5.9.2.1	AddArray	36
5.9.2.2	AddBoolean	37
5.9.2.3	AddCluster	37
5.9.2.4	AddDouble	37
5.9.2.5	AddFloat	37
5.9.2.6	AddI16	37
5.9.2.7	AddI32	37
5.9.2.8	AddI8	38
5.9.2.9	AddString	38
5.9.2.10	AddString	38
5.9.2.11	AddU16	38
5.9.2.12	AddU32	38
5.9.2.13	AddU8	38
5.9.2.14	Finalize	39
5.9.2.15	FinalizeArray	39
5.9.2.16	FinalizeCluster	39
5.9.2.17	Printf	39
5.10	DigitalInput Class Reference	40
5.10.1	Detailed Description	40
5.10.2	Constructor & Destructor Documentation	40
5.10.2.1	DigitalInput	40
5.10.2.2	DigitalInput	40
5.10.2.3	~DigitalInput	40
5.10.3	Member Function Documentation	41
5.10.3.1	GetAnalogTriggerForRouting	41
5.10.3.2	GetChannel	41
5.10.3.3	GetChannelForRouting	41
5.10.3.4	GetModuleForRouting	41
5.10.3.5	RequestInterrupts	41
5.10.3.6	RequestInterrupts	41
5.11	DigitalOutput Class Reference	43
5.11.1	Detailed Description	43
5.11.2	Constructor & Destructor Documentation	43
5.11.2.1	DigitalOutput	43

5.11.2.2	DigitalOutput	43
5.11.2.3	~DigitalOutput	43
5.11.3	Member Function Documentation	43
5.11.3.1	IsPulsing	43
5.11.3.2	Pulse	43
5.11.3.3	Set	44
5.12	DigitalSource Class Reference	45
5.12.1	Detailed Description	45
5.12.2	Constructor & Destructor Documentation	45
5.12.2.1	~DigitalSource	45
5.13	DriverStation Class Reference	46
5.13.1	Detailed Description	46
5.13.2	Constructor & Destructor Documentation	46
5.13.2.1	DriverStation	46
5.13.3	Member Function Documentation	46
5.13.3.1	GetAnalogIn	46
5.13.3.2	GetBatteryVoltage	47
5.13.3.3	GetData	47
5.13.3.4	GetDigitalIn	47
5.13.3.5	GetDigitalOut	47
5.13.3.6	GetInstance	47
5.13.3.7	GetPacketNumber	47
5.13.3.8	GetStickAxis	48
5.13.3.9	GetStickButtons	48
5.13.3.10	SetData	48
5.13.3.11	SetDigitalOut	48
5.14	Encoder Class Reference	49
5.14.1	Detailed Description	49
5.14.2	Constructor & Destructor Documentation	49
5.14.2.1	Encoder	49
5.14.2.2	Encoder	50
5.14.2.3	Encoder	50
5.14.2.4	~Encoder	50
5.14.3	Member Function Documentation	50
5.14.3.1	Get	50
5.14.3.2	GetDirection	51

5.14.3.3	GetDistance	51
5.14.3.4	GetPeriod	51
5.14.3.5	GetStopped	51
5.14.3.6	Reset	51
5.14.3.7	SetDistancePerTick	51
5.14.3.8	SetMaxPeriod	52
5.14.3.9	SetReverseDirection	52
5.14.3.10	Start	52
5.14.3.11	Stop	52
5.15	Error Class Reference	53
5.15.1	Detailed Description	53
5.16	ErrorBase Class Reference	54
5.16.1	Detailed Description	54
5.16.2	Member Function Documentation	54
5.16.2.1	GetGlobalError	54
5.16.2.2	SetError	54
5.16.2.3	StatusIsFatal	55
5.17	GearTooth Class Reference	56
5.17.1	Detailed Description	56
5.17.2	Constructor & Destructor Documentation	56
5.17.2.1	GearTooth	56
5.17.2.2	GearTooth	56
5.17.2.3	GearTooth	57
5.17.2.4	~GearTooth	57
5.17.3	Member Function Documentation	57
5.17.3.1	EnableDirectionSensing	57
5.18	GenericHID Class Reference	58
5.18.1	Detailed Description	58
5.19	Gyro Class Reference	59
5.19.1	Detailed Description	59
5.19.2	Constructor & Destructor Documentation	59
5.19.2.1	Gyro	59
5.19.2.2	Gyro	59
5.19.2.3	Gyro	60
5.19.2.4	~Gyro	60
5.19.3	Member Function Documentation	60

5.19.3.1	GetAngle	60
5.19.3.2	Reset	60
5.19.3.3	SetSensitivity	60
5.20	HiTechnicCompass Class Reference	61
5.20.1	Detailed Description	61
5.20.2	Constructor & Destructor Documentation	61
5.20.2.1	HiTechnicCompass	61
5.20.2.2	~HiTechnicCompass	61
5.20.3	Member Function Documentation	61
5.20.3.1	GetAngle	61
5.21	I2C Class Reference	63
5.21.1	Detailed Description	63
5.21.2	Constructor & Destructor Documentation	63
5.21.2.1	~I2C	63
5.21.3	Member Function Documentation	63
5.21.3.1	Broadcast	63
5.21.3.2	Read	63
5.21.3.3	VerifySensor	64
5.21.3.4	Write	64
5.22	IterativeRobot Class Reference	65
5.22.1	Detailed Description	65
5.22.2	Constructor & Destructor Documentation	66
5.22.2.1	~IterativeRobot	66
5.22.2.2	IterativeRobot	66
5.22.3	Member Function Documentation	66
5.22.3.1	AutonomousContinuous	66
5.22.3.2	AutonomousInit	66
5.22.3.3	AutonomousPeriodic	66
5.22.3.4	DisabledContinuous	66
5.22.3.5	DisabledInit	67
5.22.3.6	DisabledPeriodic	67
5.22.3.7	GetLoopsPerSec	67
5.22.3.8	RobotInit	67
5.22.3.9	SetPeriod	67
5.22.3.10	StartCompetition	67
5.22.3.11	TeleopContinuous	67

5.22.3.12 TeleopInit	68
5.22.3.13 TeleopPeriodic	68
5.23 Jaguar Class Reference	69
5.23.1 Detailed Description	69
5.23.2 Constructor & Destructor Documentation	69
5.23.2.1 Jaguar	69
5.23.2.2 Jaguar	69
5.23.3 Member Function Documentation	69
5.23.3.1 Get	69
5.23.3.2 Set	70
5.24 Joystick Class Reference	71
5.24.1 Detailed Description	71
5.24.2 Constructor & Destructor Documentation	71
5.24.2.1 Joystick	71
5.24.2.2 Joystick	71
5.24.3 Member Function Documentation	72
5.24.3.1 GetAxis	72
5.24.3.2 GetAxisChannel	72
5.24.3.3 GetBumper	72
5.24.3.4 GetButton	72
5.24.3.5 GetRawAxis	73
5.24.3.6 GetRawButton	73
5.24.3.7 GetThrottle	73
5.24.3.8 GetTop	73
5.24.3.9 GetTrigger	74
5.24.3.10 GetTwist	74
5.24.3.11 GetX	74
5.24.3.12 GetY	74
5.24.3.13 GetZ	74
5.24.3.14 SetAxisChannel	74
5.25 ParticleAnalysisReport_struct Struct Reference	76
5.25.1 Detailed Description	76
5.26 PCVideoServer Class Reference	77
5.26.1 Detailed Description	77
5.27 PIDController Class Reference	78
5.27.1 Detailed Description	78

5.27.2	Constructor & Destructor Documentation	78
5.27.2.1	PIDController	78
5.27.2.2	~PIDController	78
5.27.3	Member Function Documentation	79
5.27.3.1	Disable	79
5.27.3.2	Enable	79
5.27.3.3	Get	79
5.27.3.4	GetError	79
5.27.3.5	GetSetpoint	79
5.27.3.6	Reset	79
5.27.3.7	SetContinuous	79
5.27.3.8	SetInput	80
5.27.3.9	SetInput	80
5.27.3.10	SetOutput	80
5.27.3.11	SetOutput	80
5.27.3.12	SetSetpoint	80
5.28	PIDOutput Class Reference	81
5.28.1	Detailed Description	81
5.29	PIDSource Class Reference	82
5.29.1	Detailed Description	82
5.30	PWM Class Reference	83
5.30.1	Detailed Description	83
5.30.2	Constructor & Destructor Documentation	84
5.30.2.1	PWM	84
5.30.2.2	PWM	84
5.30.2.3	~PWM	84
5.30.3	Member Function Documentation	84
5.30.3.1	EnableDeadbandElimination	84
5.30.3.2	GetPosition	84
5.30.3.3	GetRaw	85
5.30.3.4	GetSpeed	85
5.30.3.5	SetBounds	85
5.30.3.6	SetPeriodMultiplier	85
5.30.3.7	SetPosition	86
5.30.3.8	SetRaw	86
5.30.3.9	SetSpeed	86

5.30.4	Member Data Documentation	86
5.30.4.1	kDefaultMinPwmHigh	86
5.30.4.2	kDefaultPwmPeriod	87
5.31	Relay Class Reference	88
5.31.1	Detailed Description	88
5.31.2	Constructor & Destructor Documentation	88
5.31.2.1	Relay	88
5.31.2.2	Relay	88
5.31.2.3	~Relay	88
5.31.3	Member Function Documentation	89
5.31.3.1	Set	89
5.32	Resource Class Reference	90
5.32.1	Detailed Description	90
5.32.2	Constructor & Destructor Documentation	90
5.32.2.1	~Resource	90
5.32.2.2	Resource	90
5.32.3	Member Function Documentation	90
5.32.3.1	Allocate	90
5.32.3.2	Allocate	91
5.32.3.3	Free	91
5.33	RobotBase Class Reference	92
5.33.1	Detailed Description	92
5.33.2	Constructor & Destructor Documentation	92
5.33.2.1	~RobotBase	92
5.33.2.2	RobotBase	93
5.33.3	Member Function Documentation	93
5.33.3.1	GetWatchdog	93
5.33.3.2	IsAutonomous	93
5.33.3.3	IsDisabled	93
5.33.3.4	IsNewDataAvailable	93
5.33.3.5	IsOperatorControl	93
5.33.3.6	IsSystemActive	94
5.33.3.7	robotTask	94
5.33.3.8	startRobotTask	94
5.34	RobotDeleter Class Reference	95
5.34.1	Detailed Description	95

5.35 RobotDrive Class Reference	96
5.35.1 Detailed Description	96
5.35.2 Constructor & Destructor Documentation	96
5.35.2.1 RobotDrive	96
5.35.2.2 RobotDrive	97
5.35.2.3 RobotDrive	97
5.35.2.4 RobotDrive	97
5.35.2.5 ~RobotDrive	98
5.35.3 Member Function Documentation	98
5.35.3.1 ArcadeDrive	98
5.35.3.2 ArcadeDrive	98
5.35.3.3 ArcadeDrive	98
5.35.3.4 ArcadeDrive	99
5.35.3.5 ArcadeDrive	99
5.35.3.6 Drive	99
5.35.3.7 HolonomicDrive	99
5.35.3.8 SetLeftRightMotorSpeeds	100
5.35.3.9 TankDrive	100
5.35.3.10 TankDrive	100
5.35.3.11 TankDrive	100
5.36 ScopedSocket Class Reference	101
5.36.1 Detailed Description	101
5.37 SensorBase Class Reference	102
5.37.1 Detailed Description	102
5.37.2 Constructor & Destructor Documentation	102
5.37.2.1 SensorBase	102
5.37.2.2 ~SensorBase	103
5.37.3 Member Function Documentation	103
5.37.3.1 AddToSingletonList	103
5.37.3.2 CheckAnalogChannel	103
5.37.3.3 CheckAnalogModule	103
5.37.3.4 CheckDigitalChannel	103
5.37.3.5 CheckDigitalModule	103
5.37.3.6 CheckPWMChannel	103
5.37.3.7 CheckPWMModule	103
5.37.3.8 CheckRelayChannel	103

5.37.3.9	CheckRelayModule	104
5.37.3.10	CheckSolenoidChannel	104
5.37.3.11	CheckSolenoidModule	104
5.37.3.12	DeleteSingletons	104
5.37.3.13	SetDefaultAnalogModule	104
5.37.3.14	SetDefaultDigitalModule	104
5.37.3.15	SetDefaultSolenoidModule	104
5.38	SerialPort Class Reference	105
5.38.1	Detailed Description	105
5.38.2	Constructor & Destructor Documentation	105
5.38.2.1	SerialPort	105
5.38.2.2	~SerialPort	106
5.38.3	Member Function Documentation	106
5.38.3.1	DisableTermination	106
5.38.3.2	EnableTermination	106
5.38.3.3	Flush	106
5.38.3.4	GetBytesReceived	106
5.38.3.5	Printf	106
5.38.3.6	Read	107
5.38.3.7	Reset	107
5.38.3.8	Scanf	107
5.38.3.9	SetFlowControl	107
5.38.3.10	SetTimeout	107
5.38.3.11	SetWriteBufferMode	108
5.38.3.12	Write	108
5.39	Servo Class Reference	109
5.39.1	Detailed Description	109
5.39.2	Constructor & Destructor Documentation	109
5.39.2.1	Servo	109
5.39.2.2	Servo	109
5.39.3	Member Function Documentation	109
5.39.3.1	Get	109
5.39.3.2	GetAngle	110
5.39.3.3	Set	110
5.39.3.4	SetAngle	110
5.40	SimpleRobot Class Reference	111

5.40.1	Detailed Description	111
5.40.2	Member Function Documentation	111
5.40.2.1	Autonomous	111
5.40.2.2	OperatorControl	111
5.40.2.3	RobotMain	111
5.40.2.4	StartCompetition	111
5.41	Solenoid Class Reference	113
5.41.1	Detailed Description	113
5.41.2	Constructor & Destructor Documentation	113
5.41.2.1	Solenoid	113
5.41.2.2	Solenoid	113
5.41.2.3	~Solenoid	113
5.41.3	Member Function Documentation	114
5.41.3.1	Get	114
5.41.3.2	Set	114
5.41.3.3	SlotToIndex	114
5.42	SpeedController Class Reference	115
5.42.1	Detailed Description	115
5.42.2	Member Function Documentation	115
5.42.2.1	Get	115
5.42.2.2	Set	115
5.43	Synchronized Class Reference	116
5.43.1	Detailed Description	116
5.43.2	Constructor & Destructor Documentation	116
5.43.2.1	Synchronized	116
5.43.2.2	~Synchronized	116
5.44	Task Class Reference	117
5.44.1	Detailed Description	117
5.44.2	Constructor & Destructor Documentation	117
5.44.2.1	Task	117
5.44.3	Member Function Documentation	117
5.44.3.1	GetID	117
5.44.3.2	GetName	118
5.44.3.3	GetPriority	118
5.44.3.4	IsReady	118
5.44.3.5	IsSuspended	118

5.44.3.6	Restart	118
5.44.3.7	Resume	118
5.44.3.8	SetPriority	118
5.44.3.9	Start	119
5.44.3.10	Stop	119
5.44.3.11	Suspend	119
5.44.3.12	Verify	119
5.45	Timer Class Reference	120
5.45.1	Detailed Description	120
5.45.2	Constructor & Destructor Documentation	120
5.45.2.1	Timer	120
5.45.3	Member Function Documentation	120
5.45.3.1	Get	120
5.45.3.2	Reset	120
5.45.3.3	Start	120
5.45.3.4	Stop	121
5.46	Ultrasonic Class Reference	122
5.46.1	Detailed Description	122
5.46.2	Constructor & Destructor Documentation	122
5.46.2.1	Ultrasonic	122
5.46.2.2	Ultrasonic	122
5.46.2.3	Ultrasonic	123
5.46.2.4	Ultrasonic	123
5.46.2.5	~Ultrasonic	123
5.46.3	Member Function Documentation	123
5.46.3.1	GetRangeInches	123
5.46.3.2	GetRangeMM	124
5.46.3.3	IsRangeValid	124
5.46.3.4	Ping	124
5.46.3.5	SetAutomaticMode	124
5.47	Victor Class Reference	125
5.47.1	Detailed Description	125
5.47.2	Constructor & Destructor Documentation	125
5.47.2.1	Victor	125
5.47.2.2	Victor	125
5.47.3	Member Function Documentation	125

5.47.3.1	Get	125
5.47.3.2	Set	126
5.48	Watchdog Class Reference	127
5.48.1	Detailed Description	127
5.48.2	Constructor & Destructor Documentation	127
5.48.2.1	Watchdog	127
5.48.2.2	~Watchdog	127
5.48.3	Member Function Documentation	127
5.48.3.1	Feed	127
5.48.3.2	GetEnabled	128
5.48.3.3	GetExpiration	128
5.48.3.4	GetTimer	128
5.48.3.5	IsAlive	128
5.48.3.6	IsSystemActive	128
5.48.3.7	Kill	129
5.48.3.8	SetEnabled	129
5.48.3.9	SetExpiration	129

Chapter 1

Todo List

Member [AnalogModule::VoltsToValue](#)(INT32 channel, float voltage) This assumes raw values. Oversampling not supported as is.

Class [HiTechnicCompass](#) Implement a calibration method for the sensor.

Member [RobotBase::IsNewDataAvailable](#)() The current implementation is silly. We already know this explicitly without trying to figure it out.

Class [SimpleRobot](#) If this is going to last until release, it needs a better name.

Chapter 2

Bug List

Member [SerialPort::Printf](#)(const char *writeFmt,...) All pointer-based parameters seem to return an error.

Member [SerialPort::Scanf](#)(const char *readFmt,...) All pointer-based parameters seem to return an error.

Chapter 3

Class Index

3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

AnalogModule	17
ColorReport_struct	26
CounterBase	35
Counter	29
GearTooth	56
Encoder	49
DigitalSource	45
AnalogTriggerOutput	23
DigitalInput	40
Error	53
ErrorBase	54
Dashboard	36
PCVideoServer	77
SensorBase	102
Accelerometer	9
AnalogChannel	11
Compressor	27
Counter	29
DigitalOutput	43
DriverStation	46
Encoder	49
Gyro	59
HiTechnicCompass	61
I2C	63
PWM	83
Jaguar	69
Servo	109
Victor	125
Relay	88
Solenoid	113
Ultrasonic	122
Watchdog	127

GenericHID	58
Joystick	71
ParticleAnalysisReport_struct	76
PIDController	78
PIDOutput	81
PIDSource	82
Resource	90
RobotBase	92
IterativeRobot	65
SimpleRobot	111
RobotDeleter	95
RobotDrive	96
ScopedSocket	101
SerialPort	105
SpeedController	115
Jaguar	69
Servo	109
Victor	125
Synchronized	116
Task	117
Timer	120

Chapter 4

Class Index

4.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

Accelerometer	9
AnalogChannel	11
AnalogModule	17
AnalogTriggerOutput	23
ColorReport_struct	26
Compressor	27
Counter	29
CounterBase	35
Dashboard	36
DigitalInput	40
DigitalOutput	43
DigitalSource	45
DriverStation	46
Encoder	49
Error	53
ErrorBase	54
GearTooth	56
GenericHID	58
Gyro	59
HiTechnicCompass	61
I2C	63
IterativeRobot	65
Jaguar	69
Joystick	71
ParticleAnalysisReport_struct	76
PCVideoServer	77
PIDController	78
PIDOutput	81
PIDSource	82
PWM	83
Relay	88
Resource	90
RobotBase	92

RobotDeleter	95
RobotDrive	96
ScopedSocket (Implements an object that automatically does a close on a camera socket on de- struction)	101
SensorBase	102
SerialPort	105
Servo	109
SimpleRobot	111
Solenoid	113
SpeedController	115
Synchronized	116
Task	117
Timer	120
Ultrasonic	122
Victor	125
Watchdog	127

Chapter 5

Class Documentation

5.1 Accelerometer Class Reference

```
#include <Accelerometer.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [Accelerometer](#) (UINT32 channel)
- [Accelerometer](#) (UINT32 slot, UINT32 channel)
- [Accelerometer](#) ([AnalogChannel](#) *channel)
- virtual [~Accelerometer](#) ()
- float [GetAcceleration](#) ()
- void [SetSensitivity](#) (float sensitivity)
- void [SetZero](#) (float zero)

5.1.1 Detailed Description

Handle operation of the accelerometer. The accelerometer reads acceleration directly through the sensor. Many sensors have multiple axis and can be treated as multiple devices. Each is calibrated by finding the center value over a period of time.

5.1.2 Constructor & Destructor Documentation

5.1.2.1 [Accelerometer::Accelerometer \(UINT32 *channel*\)](#) [explicit]

Create a new instance of an accelerometer.

The accelerometer is assumed to be in the first analog module in the given analog channel. The constructor allocates desired analog channel.

5.1.2.2 [Accelerometer::Accelerometer \(UINT32 *slot*, UINT32 *channel*\)](#)

Create new instance of accelerometer.

Make a new instance of the accelerometer given a module and channel. The constructor allocates the desired analog channel from the specified module

5.1.2.3 **Accelerometer::Accelerometer** (*AnalogChannel *channel*) [explicit]

Create a new instance of [Accelerometer](#) from an existing [AnalogChannel](#). Make a new instance of accelerometer given an [AnalogChannel](#). This is particularly useful if the port is going to be read as an analog channel as well as through the [Accelerometer](#) class.

5.1.2.4 **Accelerometer::~~Accelerometer** () [virtual]

Delete the analog components used for the accelerometer.

5.1.3 Member Function Documentation

5.1.3.1 **float Accelerometer::GetAcceleration** ()

Return the acceleration in Gs.

The acceleration is returned units of Gs.

Returns:

The current acceleration of the sensor in Gs.

5.1.3.2 **void Accelerometer::SetSensitivity** (*float sensitivity*)

Set the accelerometer sensitivity.

This sets the sensitivity of the accelerometer used for calculating the acceleration. The sensitivity varies by accelerometer model. There are constants defined for various models.

Parameters:

sensitivity The sensitivity of accelerometer in Volts per G.

5.1.3.3 **void Accelerometer::SetZero** (*float zero*)

Set the voltage that corresponds to 0 G.

The zero G voltage varies by accelerometer model. There are constants defined for various models.

Parameters:

zero The zero G voltage.

The documentation for this class was generated from the following files:

- Accelerometer.h
- Accelerometer.cpp

5.2 AnalogChannel Class Reference

```
#include <AnalogChannel.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [AnalogChannel](#) (UINT32 slot, UINT32 channel)
- [AnalogChannel](#) (UINT32 channel)
- virtual [~AnalogChannel](#) ()
- [AnalogModule](#) * [GetModule](#) ()
- INT16 [GetValue](#) ()
- INT32 [GetAverageValue](#) ()
- float [GetVoltage](#) ()
- float [GetAverageVoltage](#) ()
- UINT32 [GetSlot](#) ()
- UINT32 [GetChannel](#) ()
- void [SetAverageBits](#) (UINT32 bits)
- UINT32 [GetAverageBits](#) ()
- void [SetOversampleBits](#) (UINT32 bits)
- UINT32 [GetOversampleBits](#) ()
- UINT32 [GetLSBWeight](#) ()
- INT32 [GetOffset](#) ()
- bool [IsAccumulatorChannel](#) ()
- void [InitAccumulator](#) ()
- void [SetAccumulatorInitialValue](#) (INT64 value)
- void [ResetAccumulator](#) ()
- void [SetAccumulatorCenter](#) (INT32 center)
- void [SetAccumulatorDeadband](#) (INT32 deadband)
- INT64 [GetAccumulatorValue](#) ()
- UINT32 [GetAccumulatorCount](#) ()
- void [GetAccumulatorOutput](#) (INT64 *value, UINT32 *count)

5.2.1 Detailed Description

Analog channel class.

Each analog channel is read from hardware as a 12-bit number representing -10V to 10V.

Connected to each analog channel is an averaging and oversampling engine. This engine accumulates the specified (by [SetAverageBits\(\)](#) and [SetOversampleBits\(\)](#)) number of samples before returning a new value. This is not a sliding window average. The only difference between the oversampled samples and the averaged samples is that the oversampled samples are simply accumulated effectively increasing the resolution, while the averaged samples are divided by the number of samples to retain the resolution, but get more stable values.

5.2.2 Constructor & Destructor Documentation

5.2.2.1 AnalogChannel::AnalogChannel (UINT32 *slot*, UINT32 *channel*)

Construct an analog channel on a specified module.

Parameters:

slot The slot that the analog module is plugged into.

channel The channel number to represent.

5.2.2.2 AnalogChannel::AnalogChannel (UINT32 *channel*) [explicit]

Construct an analog channel on the default module.

Parameters:

channel The channel number to represent.

5.2.2.3 AnalogChannel::~~AnalogChannel () [virtual]

Channel destructor.

5.2.3 Member Function Documentation

5.2.3.1 UINT32 AnalogChannel::GetAccumulatorCount ()

Read the number of accumulated values.

Read the count of the accumulated values since the accumulator was last Reset().

Returns:

The number of times samples from the channel were accumulated.

5.2.3.2 void AnalogChannel::GetAccumulatorOutput (INT64 * *value*, UINT32 * *count*)

Read the accumulated value and the number of accumulated values atomically.

This function reads the value and count from the FPGA atomically. This can be used for averaging.

Parameters:

value Pointer to the 64-bit accumulated output.

count Pointer to the number of accumulation cycles.

5.2.3.3 INT64 AnalogChannel::GetAccumulatorValue ()

Read the accumulated value.

Read the value that has been accumulating on channel 1. The accumulator is attached after the oversample and average engine.

Returns:

The 64-bit value accumulated since the last Reset().

5.2.3.4 UINT32 AnalogChannel::GetAverageBits ()

Get the number of averaging bits previously configured. This gets the number of averaging bits from the FPGA. The actual number of averaged samples is 2^{bits} . The averaging is done automatically in the FPGA.

Returns:

Number of bits of averaging previously configured.

5.2.3.5 INT32 AnalogChannel::GetAverageValue ()

Get a sample from the output of the oversample and average engine for this channel. The sample is 12-bit + the value configured in [SetOversampleBits\(\)](#). The value configured in [SetAverageBits\(\)](#) will cause this value to be averaged 2^{bits} number of samples. This is not a sliding window. The sample will not change until $2^{(OversampleBits + AverageBits)}$ samples have been acquired from the module on this channel. Use [GetAverageVoltage\(\)](#) to get the analog value in calibrated units.

Returns:

A sample from the oversample and average engine for this channel.

5.2.3.6 float AnalogChannel::GetAverageVoltage ()

Get a scaled sample from the output of the oversample and average engine for this channel. The value is scaled to units of Volts using the calibrated scaling data from [GetLSBWeight\(\)](#) and [GetOffset\(\)](#). Using oversampling will cause this value to be higher resolution, but it will update more slowly. Using averaging will cause this value to be more stable, but it will update more slowly.

Returns:

A scaled sample from the output of the oversample and average engine for this channel.

5.2.3.7 UINT32 AnalogChannel::GetChannel ()

Get the channel number.

Returns:

The channel number.

5.2.3.8 `UINT32 AnalogChannel::GetLSBWeight ()`

Get the factory scaling least significant bit weight constant. The least significant bit weight constant for the channel that was calibrated in manufacturing and stored in an eeprom in the module.

$\text{Volts} = ((\text{LSB_Weight} * 1\text{e-}9) * \text{raw}) - (\text{Offset} * 1\text{e-}9)$

Returns:

Least significant bit weight.

5.2.3.9 `AnalogModule * AnalogChannel::GetModule ()`

Get the analog module that this channel is on.

Returns:

A pointer to the [AnalogModule](#) that this channel is on.

5.2.3.10 `INT32 AnalogChannel::GetOffset ()`

Get the factory scaling offset constant. The offset constant for the channel that was calibrated in manufacturing and stored in an eeprom in the module.

$\text{Volts} = ((\text{LSB_Weight} * 1\text{e-}9) * \text{raw}) - (\text{Offset} * 1\text{e-}9)$

Returns:

Offset constant.

5.2.3.11 `UINT32 AnalogChannel::GetOversampleBits ()`

Get the number of oversample bits previously configured. This gets the number of oversample bits from the FPGA. The actual number of oversampled values is $2^{*\text{bits}}$. The oversampling is done automatically in the FPGA.

Returns:

Number of bits of oversampling previously configured.

5.2.3.12 `UINT32 AnalogChannel::GetSlot ()`

Get the slot that the analog module is plugged into.

Returns:

The slot that the analog module is plugged into.

5.2.3.13 INT16 AnalogChannel::GetValue ()

Get a sample straight from this channel on the module. The sample is a 12-bit value representing the -10V to 10V range of the A/D converter in the module. The units are in A/D converter codes. Use [GetVoltage\(\)](#) to get the analog value in calibrated units.

Returns:

A sample straight from this channel on the module.

5.2.3.14 float AnalogChannel::GetVoltage ()

Get a scaled sample straight from this channel on the module. The value is scaled to units of Volts using the calibrated scaling data from [GetLSBWeight\(\)](#) and [GetOffset\(\)](#).

Returns:

A scaled sample straight from this channel on the module.

5.2.3.15 void AnalogChannel::InitAccumulator ()

Initialize the accumulator.

5.2.3.16 bool AnalogChannel::IsAccumulatorChannel ()

Is the channel attached to an accumulator.

Returns:

The analog channel is attached to an accumulator.

5.2.3.17 void AnalogChannel::ResetAccumulator ()

Resets the accumulator to the initial value.

5.2.3.18 void AnalogChannel::SetAccumulatorCenter (INT32 *center*)

Set the center value of the accumulator.

The center value is subtracted from each A/D value before it is added to the accumulator. This is used for the center value of devices like gyros and accelerometers to make integration work and to take the device offset into account when integrating.

This center value is based on the output of the oversampled and averaged source from channel 1. Because of this, any non-zero oversample bits will affect the size of the value for this field.

5.2.3.19 void AnalogChannel::SetAccumulatorDeadband (INT32 *deadband*)

Set the accumulator's deadband.

5.2.3.20 void AnalogChannel::SetAccumulatorInitialValue (INT64 *initialValue*)

Set an initial value for the accumulator.

This will be added to all values returned to the user.

Parameters:

initialValue The value that the accumulator should start from when reset.

5.2.3.21 void AnalogChannel::SetAverageBits (UINT32 *bits*)

Set the number of averaging bits. This sets the number of averaging bits. The actual number of averaged samples is $2 \times \text{bits}$. Use averaging to improve the stability of your measurement at the expense of sampling rate. The averaging is done automatically in the FPGA.

Parameters:

bits Number of bits of averaging.

5.2.3.22 void AnalogChannel::SetOversampleBits (UINT32 *bits*)

Set the number of oversample bits. This sets the number of oversample bits. The actual number of oversampled values is $2 \times \text{bits}$. Use oversampling to improve the resolution of your measurements at the expense of sampling rate. The oversampling is done automatically in the FPGA.

Parameters:

bits Number of bits of oversampling.

The documentation for this class was generated from the following files:

- AnalogChannel.h
- AnalogChannel.cpp

5.3 AnalogModule Class Reference

```
#include <AnalogModule.h>
```

Inherits Module.

Public Member Functions

- void [SetSampleRate](#) (float samplesPerSecond)
- float [GetSampleRate](#) ()
- void [SetAverageBits](#) (UINT32 channel, UINT32 bits)
- UINT32 [GetAverageBits](#) (UINT32 channel)
- void [SetOversampleBits](#) (UINT32 channel, UINT32 bits)
- UINT32 [GetOversampleBits](#) (UINT32 channel)
- INT16 [GetValue](#) (UINT32 channel)
- INT32 [GetAverageValue](#) (UINT32 channel)
- float [GetAverageVoltage](#) (UINT32 channel)
- float [GetVoltage](#) (UINT32 channel)
- UINT32 [GetLSBWeight](#) (UINT32 channel)
- INT32 [GetOffset](#) (UINT32 channel)
- INT32 [VoltsToValue](#) (INT32 channel, float voltage)

Static Public Member Functions

- static UINT32 [SlotToIndex](#) (UINT32 slot)
- static [AnalogModule](#) * [GetInstance](#) (UINT32 slot)

Static Public Attributes

- static const long [kTimebase](#) = 40000000
40 MHz clock

Protected Member Functions

- [AnalogModule](#) (UINT32 slot)
- virtual [~AnalogModule](#) ()

5.3.1 Detailed Description

Analog Module class. Each module can independently sample its channels at a configurable rate. There is a 64-bit hardware accumulator associated with channel 1 on each module. The accumulator is attached to the output of the oversample and average engine so that the center value can be specified in higher resolution resulting in less error.

5.3.2 Constructor & Destructor Documentation

5.3.2.1 `AnalogModule::AnalogModule (UINT32 slot)` [`explicit`, `protected`]

Create a new instance of an analog module.

Create an instance of the analog module object. Initialize all the parameters to reasonable values on start. Setting a global value on an analog module can be done only once unless subsequent values are set the previously set value. Analog modules are a singleton, so the constructor is never called outside of this class.

Parameters:

slot The slot in the chassis that the module is plugged into.

5.3.2.2 `AnalogModule::~~AnalogModule ()` [`protected`, `virtual`]

Destructor for [AnalogModule](#).

5.3.3 Member Function Documentation

5.3.3.1 `UINT32 AnalogModule::GetAverageBits (UINT32 channel)`

Get the number of averaging bits.

This gets the number of averaging bits from the FPGA. The actual number of averaged samples is 2^{**}bits . The averaging is done automatically in the FPGA.

Parameters:

channel Channel to address.

Returns:

Bits to average.

5.3.3.2 `INT32 AnalogModule::GetAverageValue (UINT32 channel)`

Get a sample from the output of the oversample and average engine for the channel.

The sample is 12-bit + the value configured in [SetOversampleBits\(\)](#). The value configured in [SetAverageBits\(\)](#) will cause this value to be averaged 2^{**}bits number of samples. This is not a sliding window. The sample will not change until $2^{**}(\text{OversampleBits} + \text{AverageBits})$ samples have been acquired from the module on this channel. Use [GetAverageVoltage\(\)](#) to get the analog value in calibrated units.

Parameters:

channel Channel number to read.

Returns:

A sample from the oversample and average engine for the channel.

5.3.3.3 float AnalogModule::GetAverageVoltage (UINT32 *channel*)

Get a scaled sample from the output of the oversample and average engine for the channel.

The value is scaled to units of Volts using the calibrated scaling data from [GetLSBWeight\(\)](#) and [GetOffset\(\)](#). Using oversampling will cause this value to be higher resolution, but it will update more slowly. Using averaging will cause this value to be more stable, but it will update more slowly.

Parameters:

channel The channel to read.

Returns:

A scaled sample from the output of the oversample and average engine for the channel.

5.3.3.4 AnalogModule * AnalogModule::GetInstance (UINT32 *slot*) [static]

Get an instance of an Analog Module.

Singleton analog module creation where a module is allocated on the first use and the same module is returned on subsequent uses.

Parameters:

slot The physical slot in the cRIO chassis where this analog module is installed.

Returns:

A pointer to the [AnalogModule](#).

5.3.3.5 UINT32 AnalogModule::GetLSBWeight (UINT32 *channel*)

Get the factory scaling least significant bit weight constant. The least significant bit weight constant for the channel that was calibrated in manufacturing and stored in an eeprom in the module.

$\text{Volts} = ((\text{LSB_Weight} * 1\text{e-}9) * \text{raw}) - (\text{Offset} * 1\text{e-}9)$

Parameters:

channel The channel to get calibration data for.

Returns:

Least significant bit weight.

5.3.3.6 INT32 AnalogModule::GetOffset (UINT32 *channel*)

Get the factory scaling offset constant. The offset constant for the channel that was calibrated in manufacturing and stored in an eeprom in the module.

$\text{Volts} = ((\text{LSB_Weight} * 1\text{e-}9) * \text{raw}) - (\text{Offset} * 1\text{e-}9)$

Parameters:

channel The channel to get calibration data for.

Returns:

Offset constant.

5.3.3.7 UINT32 AnalogModule::GetOversampleBits (UINT32 *channel*)

Get the number of oversample bits.

This gets the number of oversample bits from the FPGA. The actual number of oversampled values is 2**bits. The oversampling is done automatically in the FPGA.

Parameters:

channel Channel to address.

Returns:

Bits to oversample.

5.3.3.8 float AnalogModule::GetSampleRate ()

Get the current sample rate on the module.

This assumes one entry in the scan list. This is a global setting for the module and effects all channels.

Returns:

Sample rate.

5.3.3.9 INT16 AnalogModule::GetValue (UINT32 *channel*)

Get a sample straight from the channel on this module.

The sample is a 12-bit value representing the -10V to 10V range of the A/D converter in the module. The units are in A/D converter codes. Use [GetVoltage\(\)](#) to get the analog value in calibrated units.

Returns:

A sample straight from the channel on this module.

5.3.3.10 float AnalogModule::GetVoltage (UINT32 *channel*)

Get a scaled sample straight from the channel on this module.

The value is scaled to units of Volts using the calibrated scaling data from [GetLSBWeight\(\)](#) and [GetOffset\(\)](#).

Parameters:

channel The channel to read.

Returns:

A scaled sample straight from the channel on this module.

5.3.3.11 void AnalogModule::SetAverageBits (UINT32 *channel*, UINT32 *bits*)

Set the number of averaging bits.

This sets the number of averaging bits. The actual number of averaged samples is 2**bits. Use averaging to improve the stability of your measurement at the expense of sampling rate. The averaging is done automatically in the FPGA.

Parameters:

channel Analog channel to configure.

bits Number of bits to average.

5.3.3.12 void AnalogModule::SetOversampleBits (UINT32 *channel*, UINT32 *bits*)

Set the number of oversample bits.

This sets the number of oversample bits. The actual number of oversampled values is 2**bits. Use oversampling to improve the resolution of your measurements at the expense of sampling rate. The oversampling is done automatically in the FPGA.

Parameters:

channel Analog channel to configure.

bits Number of bits to oversample.

5.3.3.13 void AnalogModule::SetSampleRate (float *samplesPerSecond*)

Set the sample rate on the module.

This is a global setting for the module and effects all channels.

Parameters:

samplesPerSecond The number of samples per channel per second.

5.3.3.14 UINT32 AnalogModule::SlotToIndex (UINT32 *slot*) [static]

Convert slot number to index.

Parameters:

slot The slot in the chassis where the module is plugged in.

Returns:

An index to represent the module internally.

5.3.3.15 INT32 AnalogModule::VoltsToValue (INT32 *channel*, float *voltage*)

Convert a voltage to a raw value for a specified channel.

This process depends on the calibration of each channel, so the channel must be specified.

Todo

This assumes raw values. Oversampling not supported as is.

Parameters:

channel The channel to convert for.

voltage The voltage to convert.

Returns:

The raw value for the channel.

The documentation for this class was generated from the following files:

- AnalogModule.h
- AnalogModule.cpp

5.4 AnalogTriggerOutput Class Reference

```
#include <AnalogTriggerOutput.h>
```

Inherits [DigitalSource](#).

Public Member Functions

- bool [Get](#) ()
- virtual UINT32 [GetChannelForRouting](#) ()
- virtual UINT32 [GetModuleForRouting](#) ()
- virtual bool [GetAnalogTriggerForRouting](#) ()
- virtual void [RequestInterrupts](#) (tInterruptHandler handler)
Asynchronous handler version.
- virtual void [RequestInterrupts](#) ()
Synchronous Wait version.

Protected Member Functions

- [AnalogTriggerOutput](#) (AnalogTrigger *trigger, Type outputType)

5.4.1 Detailed Description

Class to represent a specific output from an analog trigger. This class is used to get the current output value and also as a [DigitalSource](#) to provide routing of an output to digital subsystems on the FPGA such as [Counter](#), [Encoder](#), and [Interrupt](#).

The TriggerState output indicates the primary output value of the trigger. If the analog signal is less than the lower limit, the output is false. If the analog value is greater than the upper limit, then the output is true. If the analog value is in between, then the trigger output state maintains its most recent value.

The InWindow output indicates whether or not the analog signal is inside the range defined by the limits.

The RisingPulse and FallingPulse outputs detect an instantaneous transition from above the upper limit to below the lower limit, and vice versa. These pulses represent a rollover condition of a sensor and can be routed to an up / down counter or to interrupts. Because the outputs generate a pulse, they cannot be read directly. To help ensure that a rollover condition is not missed, there is an average rejection filter available that operates on the upper 8 bits of a 12 bit number and selects the nearest outlier of 3 samples. This will reject a sample that is (due to averaging or sampling) errantly between the two limits. This filter will fail if more than one sample in a row is errantly in between the two limits. You may see this problem if attempting to use this feature with a mechanical rollover sensor, such as a 360 degree no-stop potentiometer without signal conditioning, because the rollover transition is not sharp / clean enough. Using the averaging engine may help with this, but rotational speeds of the sensor will then be limited.

5.4.2 Constructor & Destructor Documentation

5.4.2.1 AnalogTriggerOutput::AnalogTriggerOutput (AnalogTrigger * trigger, AnalogTriggerOutput::Type outputType) [protected]

Create an object that represents one of the four outputs from an analog trigger.

Because this class derives from [DigitalSource](#), it can be passed into routing functions for [Counter](#), [Encoder](#), etc.

Parameters:

trigger A pointer to the trigger for which this is an output.

outputType An enum that specifies the output on the trigger to represent.

5.4.3 Member Function Documentation

5.4.3.1 bool AnalogTriggerOutput::Get ()

Get the state of the analog trigger output.

Returns:

The state of the analog trigger output.

5.4.3.2 bool AnalogTriggerOutput::GetAnalogTriggerForRouting () [virtual]

Returns:

The value to be written to the module field of a routing mux.

Implements [DigitalSource](#).

5.4.3.3 UINT32 AnalogTriggerOutput::GetChannelForRouting () [virtual]

Returns:

The value to be written to the channel field of a routing mux.

Implements [DigitalSource](#).

5.4.3.4 UINT32 AnalogTriggerOutput::GetModuleForRouting () [virtual]

Returns:

The value to be written to the module field of a routing mux.

Implements [DigitalSource](#).

5.4.3.5 void AnalogTriggerOutput::RequestInterrupts () [virtual]

Synchronous Wait version.

Request interrupts synchronously on this digital input.

Implements [DigitalSource](#).

5.4.3.6 void AnalogTriggerOutput::RequestInterrupts (tInterruptHandler *handler*) [virtual]

Asynchronous handler version.

Request interrupts asynchronously on this digital input.

Implements [DigitalSource](#).

The documentation for this class was generated from the following files:

- AnalogTriggerOutput.h
- AnalogTriggerOutput.cpp

5.5 ColorReport_struct Struct Reference

```
#include <VisionAPI.h>
```

5.5.1 Detailed Description

Tracking functions return this structure

The documentation for this struct was generated from the following file:

- VisionAPI.h

5.6 Compressor Class Reference

```
#include <Compressor.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [Compressor](#) (UINT32 pressureSwitchChannel, UINT32 compressorRelayChannel)
- [Compressor](#) (UINT32 pressureSwitchSlot, UINT32 pressureSwitchChannel, UINT32 compressorRelaySlot, UINT32 compressorRelayChannel)
- [~Compressor](#) ()
- void [Start](#) ()
- void [Stop](#) ()
- bool [Enabled](#) ()
- UINT32 [GetPressureSwitchValue](#) ()
- void [SetRelayValue](#) (Relay::Value relayValue)

5.6.1 Detailed Description

[Compressor](#) object. The [Compressor](#) object is designed to handle the operation of the compressor, pressure sensor and relay for a FIRST robot pneumatics system. The [Compressor](#) object starts a task which runs in the background and periodically polls the pressure sensor and operates the relay that controls the compressor.

5.6.2 Constructor & Destructor Documentation

5.6.2.1 [Compressor::Compressor](#) (UINT32 *pressureSwitchChannel*, UINT32 *compressorRelayChannel*)

[Compressor](#) constructor. Given a relay channel and pressure switch channel (both in the default digital module), initialize the [Compressor](#) object.

Parameters:

pressureSwitchChannel The GPIO channel that the pressure switch is attached to.

compressorRelayChannel The relay channel that the compressor relay is attached to.

5.6.2.2 [Compressor::Compressor](#) (UINT32 *pressureSwitchSlot*, UINT32 *pressureSwitchChannel*, UINT32 *compressorRelaySlot*, UINT32 *compressorRelayChannel*)

[Compressor](#) constructor. Given a fully specified relay channel and pressure switch channel, initialize the [Compressor](#) object.

Parameters:

pressureSwitchSlot The module that the pressure switch is attached to.

pressureSwitchChannel The GPIO channel that the pressure switch is attached to.

compressorRelaySlot The module that the compressor relay is attached to.

compressorRelayChannel The relay channel that the compressor relay is attached to.

5.6.2.3 Compressor::~~Compressor ()

Delete the [Compressor](#) object. Delete the allocated resources for the compressor and kill the compressor task that is polling the pressure switch.

5.6.3 Member Function Documentation

5.6.3.1 bool Compressor::Enabled ()

Get the state of the enabled flag. Return the state of the enabled flag for the compressor and pressure switch combination.

Returns:

The state of the compressor thread's enable flag.

5.6.3.2 UINT32 Compressor::GetPressureSwitchValue ()

Get the pressure switch value. Read the pressure switch digital input.

Returns:

The current state of the pressure switch.

5.6.3.3 void Compressor::SetRelayValue (Relay::Value *relayValue*)

Operate the relay for the compressor. Change the value of the relay output that is connected to the compressor motor. This is only intended to be called by the internal polling thread.

5.6.3.4 void Compressor::Start ()

Start the compressor. This method will allow the polling loop to actually operate the compressor.

5.6.3.5 void Compressor::Stop ()

Stop the compressor. This method will stop the compressor from turning on.

The documentation for this class was generated from the following files:

- Compressor.h
- Compressor.cpp

5.7 Counter Class Reference

```
#include <Counter.h>
```

Inherits [SensorBase](#), and [CounterBase](#).

Inherited by [GearTooth](#).

Public Member Functions

- [Counter](#) ()
- [Counter](#) (UINT32 channel)
- [Counter](#) (UINT32 slot, UINT32 channel)
- [Counter](#) ([DigitalSource](#) *source)
- [Counter](#) ([AnalogTrigger](#) *trigger)
- virtual [~Counter](#) ()
- void [SetUpSource](#) (UINT32 channel)
- void [SetUpSource](#) (UINT32 slot, UINT32 channel)
- void [SetUpSource](#) ([AnalogTrigger](#) *analogTrigger, [AnalogTriggerOutput::Type](#) triggerType)
- void [SetUpSource](#) ([AnalogTrigger](#) &analogTrigger, [AnalogTriggerOutput::Type](#) triggerType)
- void [SetUpSource](#) ([DigitalSource](#) *source)
- void [SetUpSource](#) ([DigitalSource](#) &source)
- void [SetUpSourceEdge](#) (bool risingEdge, bool fallingEdge)
- void [ClearUpSource](#) ()
- void [SetDownSource](#) (UINT32 channel)
- void [SetDownSource](#) (UINT32 slot, UINT32 channel)
- void [SetDownSource](#) ([AnalogTrigger](#) *analogTrigger, [AnalogTriggerOutput::Type](#) triggerType)
- void [SetDownSource](#) ([AnalogTrigger](#) &analogTrigger, [AnalogTriggerOutput::Type](#) triggerType)
- void [SetDownSource](#) ([DigitalSource](#) *source)
- void [SetDownSource](#) ([DigitalSource](#) &source)
- void [SetDownSourceEdge](#) (bool risingEdge, bool fallingEdge)
- void [ClearDownSource](#) ()
- void [SetUpDownCounterMode](#) ()
- void [SetExternalDirectionMode](#) ()
- void [SetSemiPeriodMode](#) (bool highRisingPeriod)
- void [SetPulseLengthMode](#) (float threshold)
- void [Start](#) ()
- INT32 [Get](#) ()
- void [Reset](#) ()
- void [Stop](#) ()
- void [SetMaxPeriod](#) (double maxPeriod)
- void [SetUpdateWhenEmpty](#) (bool enabled)
- bool [GetStopped](#) ()
- bool [GetDirection](#) ()

5.7.1 Detailed Description

Class for counting the number of ticks on a digital input channel. This is a general purpose class for counting repetitive events. It can return the number of counts, the period of the most recent cycle, and detect when the signal being counted has stopped by supplying a maximum cycle time.

5.7.2 Constructor & Destructor Documentation

5.7.2.1 Counter::Counter ()

Create an instance of a counter where no sources are selected. Then they all must be selected by calling functions to specify the upsource and the downsource independently.

5.7.2.2 Counter::Counter (UINT32 *channel*) [explicit]

Create an instance of a [Counter](#) object. Create an up-Counter instance given a channel. The default digital module is assumed.

5.7.2.3 Counter::Counter (UINT32 *slot*, UINT32 *channel*)

Create an instance of a [Counter](#) object. Create an instance of an up-Counter given a digital module and a channel.

Parameters:

slot The cRIO chassis slot for the digital module used

channel The channel in the digital module

5.7.2.4 Counter::Counter (DigitalSource * *source*) [explicit]

Create an instance of a counter from a Digital Input. This is used if an existing digital input is to be shared by multiple other objects such as encoders.

5.7.2.5 Counter::Counter (AnalogTrigger * *trigger*) [explicit]

Create an instance of a [Counter](#) object. Create an instance of a simple up-Counter given an analog trigger. Use the trigger state output from the analog trigger.

5.7.2.6 Counter::~~Counter () [virtual]

Delete the [Counter](#) object.

5.7.3 Member Function Documentation

5.7.3.1 void Counter::ClearDownSource ()

Disable the down counting source to the counter.

5.7.3.2 void Counter::ClearUpSource ()

Disable the up counting source to the counter.

5.7.3.3 INT32 Counter::Get () [virtual]

Read the current counter value. Read the value at this instant. It may still be running, so it reflects the current value. Next time it is read, it might have a different value.

Implements [CounterBase](#).

5.7.3.4 bool Counter::GetDirection () [virtual]

The last direction the counter value changed.

Returns:

The last direction the counter value changed.

Implements [CounterBase](#).

5.7.3.5 bool Counter::GetStopped () [virtual]

Determine if the clock is stopped. Determine if the clocked input is stopped based on the MaxPeriod value set using the SetMaxPeriod method. If the clock exceeds the MaxPeriod, then the device (and counter) are assumed to be stopped and it returns true.

Returns:

Returns true if the most recent counter period exceeds the MaxPeriod value set by SetMaxPeriod.

Implements [CounterBase](#).

5.7.3.6 void Counter::Reset () [virtual]

Reset the [Counter](#) to zero. Set the counter value to zero. This doesn't effect the running state of the counter, just sets the current value to zero.

Implements [CounterBase](#).

5.7.3.7 void Counter::SetDownSource (DigitalSource & source)

Set the source object that causes the counter to count down. Set the down counting [DigitalSource](#).

5.7.3.8 void Counter::SetDownSource (DigitalSource * source)

Set the source object that causes the counter to count down. Set the down counting [DigitalSource](#).

5.7.3.9 void Counter::SetDownSource (AnalogTrigger & analogTrigger, AnalogTriggerOutput::Type triggerType)

Set the down counting source to be an analog trigger.

Parameters:

analogTrigger The analog trigger object that is used for the Down Source

triggerType The analog trigger output that will trigger the counter.

5.7.3.10 void Counter::SetDownSource (AnalogTrigger * *analogTrigger*, AnalogTriggerOutput::Type *triggerType*)

Set the down counting source to be an analog trigger.

Parameters:

analogTrigger The analog trigger object that is used for the Down Source

triggerType The analog trigger output that will trigger the counter.

5.7.3.11 void Counter::SetDownSource (UINT32 *slot*, UINT32 *channel*)

Set the down counting source to be a digital input slot and channel.

5.7.3.12 void Counter::SetDownSource (UINT32 *channel*)

Set the down counting source to be a digital input channel. The slot will be set to the default digital module slot.

5.7.3.13 void Counter::SetDownSourceEdge (bool *risingEdge*, bool *fallingEdge*)

Set the edge sensitivity on a down counting source. Set the down source to either detect rising edges or falling edges.

5.7.3.14 void Counter::SetExternalDirectionMode ()

Set external direction mode on this counter. Counts are sourced on the Up counter input. The Down counter input represents the direction to count.

5.7.3.15 void Counter::SetMaxPeriod (double *maxPeriod*) [virtual]

Set the maximum period where the device is still considered "moving". Sets the maximum period where the device is considered moving. This value is used to determine the "stopped" state of the counter using the GetStopped method.

Parameters:

maxPeriod The maximum period where the counted device is considered moving in seconds.

Implements [CounterBase](#).

5.7.3.16 void Counter::SetPulseLengthMode (float *threshold*)

Configure the counter to count in up or down based on the length of the input pulse. This mode is most useful for direction sensitive gear tooth sensors.

Parameters:

threshold The pulse length beyond which the counter counts the opposite direction. Units are seconds.

5.7.3.17 void Counter::SetSemiPeriodMode (bool *highSemiPeriod*)

Set Semi-period mode on this counter. Counts up on both rising and falling edges.

5.7.3.18 void Counter::SetUpUpdateWhenEmpty (bool *enabled*)

Select whether you want to continue updating the event timer output when there are no samples captured. The output of the event timer has a buffer of periods that are averaged and posted to a register on the FPGA. When the timer detects that the event source has stopped (based on the MaxPeriod) the buffer of samples to be averaged is emptied. If you enable the update when empty, you will be notified of the stopped source and the event time will report 0 samples. If you disable update when empty, the most recent average will remain on the output until a new sample is acquired. You will never see 0 samples output (except when there have been no events since an FPGA reset) and you will likely not see the stopped bit become true (since it is updated at the end of an average and there are no samples to average).

5.7.3.19 void Counter::SetUpDownCounterMode ()

Set standard up / down counting mode on this counter. Up and down counts are sourced independently from two inputs.

5.7.3.20 void Counter::SetUpSource (DigitalSource & *source*)

Set the source object that causes the counter to count up. Set the up counting [DigitalSource](#).

5.7.3.21 void Counter::SetUpSource (DigitalSource * *source*)

Set the source object that causes the counter to count up. Set the up counting [DigitalSource](#).

5.7.3.22 void Counter::SetUpSource (AnalogTrigger & *analogTrigger*, AnalogTriggerOutput::Type *triggerType*)

Set the up counting source to be an analog trigger.

Parameters:

analogTrigger The analog trigger object that is used for the Up Source

triggerType The analog trigger output that will trigger the counter.

5.7.3.23 void Counter::SetUpSource (AnalogTrigger * *analogTrigger*, AnalogTriggerOutput::Type *triggerType*)

Set the up counting source to be an analog trigger.

Parameters:

analogTrigger The analog trigger object that is used for the Up Source

triggerType The analog trigger output that will trigger the counter.

5.7.3.24 void Counter::SetUpSource (UINT32 *slot*, UINT32 *channel*)

Set the up source for the counter as digital input channel and slot.

5.7.3.25 void Counter::SetUpSource (UINT32 *channel*)

Set the upsource for the counter as a digital input channel. The slot will be the default digital module slot.

5.7.3.26 void Counter::SetUpSourceEdge (bool *risingEdge*, bool *fallingEdge*)

Set the edge sensitivity on an up counting source. Set the up source to either detect rising edges or falling edges.

5.7.3.27 void Counter::Start () [virtual]

Start the [Counter](#) counting. This enables the counter and it starts accumulating counts from the associated input channel. The counter value is not reset on starting, and still has the previous value.

Implements [CounterBase](#).

5.7.3.28 void Counter::Stop () [virtual]

Stop the [Counter](#). Stops the counting but doesn't effect the current value.

Implements [CounterBase](#).

The documentation for this class was generated from the following files:

- Counter.h
- Counter.cpp

5.8 CounterBase Class Reference

```
#include <CounterBase.h>
```

Inherited by [Counter](#), and [Encoder](#).

5.8.1 Detailed Description

Interface for counting the number of ticks on a digital input channel. Encoders, Gear tooth sensors, and counters should all subclass this so it can be used to build more advanced classes for control and driving.

The documentation for this class was generated from the following file:

- CounterBase.h

5.9 Dashboard Class Reference

```
#include <Dashboard.h>
```

Inherits [ErrorBase](#).

Public Member Functions

- void [AddI8](#) (INT8 value)
- void [AddI16](#) (INT16 value)
- void [AddI32](#) (INT32 value)
- void [AddU8](#) (UINT8 value)
- void [AddU16](#) (UINT16 value)
- void [AddU32](#) (UINT32 value)
- void [AddFloat](#) (float value)
- void [AddDouble](#) (double value)
- void [AddBoolean](#) (bool value)
- void [AddString](#) (char *value)
- void [AddString](#) (char *value, INT32 length)
- void [AddArray](#) (void)
- void [FinalizeArray](#) (void)
- void [AddCluster](#) (void)
- void [FinalizeCluster](#) (void)
- void [Printf](#) (const char *writeFmt,...)
- INT32 [Finalize](#) (void)

Friends

- class [DriverStation](#)

5.9.1 Detailed Description

Pack data into the "user data" field that gets sent to the dashboard laptop via the driver station.

5.9.2 Member Function Documentation

5.9.2.1 void Dashboard::AddArray (void)

Start an array in the packed dashboard data structure.

After calling [AddArray\(\)](#), call the appropriate Add method for each element of the array. Make sure you call the same add each time. An array must contain elements of the same type. You can use clusters inside of arrays to make each element of the array contain a structure of values. You can also nest arrays inside of other arrays. Every call to [AddArray\(\)](#) must have a matching call to [FinalizeArray\(\)](#).

5.9.2.2 void Dashboard::AddBoolean (bool *value*)

Pack a boolean into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.3 void Dashboard::AddCluster (void)

Start a cluster in the packed dashboard data structure.

After calling [AddCluster\(\)](#), call the appropriate Add method for each element of the cluster. You can use clusters inside of arrays to make each element of the array contain a structure of values. Every call to [AddCluster\(\)](#) must have a matching call to [FinalizeCluster\(\)](#).

5.9.2.4 void Dashboard::AddDouble (double *value*)

Pack a 64-bit floating point number into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.5 void Dashboard::AddFloat (float *value*)

Pack a 32-bit floating point number into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.6 void Dashboard::AddI16 (INT16 *value*)

Pack a signed 16-bit int into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.7 void Dashboard::AddI32 (INT32 *value*)

Pack a signed 32-bit int into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.8 void Dashboard::AddI8 (INT8 *value*)

Pack a signed 8-bit int into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.9 void Dashboard::AddString (char * *value*, INT32 *length*)

Pack a string of 8-bit characters of specified length into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

length The number of bytes in the string to pack.

5.9.2.10 void Dashboard::AddString (char * *value*)

Pack a NULL-terminated string of 8-bit characters into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.11 void Dashboard::AddU16 (UINT16 *value*)

Pack an unsigned 16-bit int into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.12 void Dashboard::AddU32 (UINT32 *value*)

Pack an unsigned 32-bit int into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.13 void Dashboard::AddU8 (UINT8 *value*)

Pack an unsigned 8-bit int into the dashboard data structure.

Parameters:

value Data to be packed into the structure.

5.9.2.14 INT32 Dashboard::Finalize (void)

Indicate that the packing is complete and commit the buffer to the [DriverStation](#).

The packing of the dashboard packet is complete. If you are not using the packed dashboard data, you can call [Finalize\(\)](#) to commit the [Printf\(\)](#) buffer and the error string buffer. In effect, you are packing an empty structure. Prepares a packet to go to the dashboard... Pack the sequence number, [Printf\(\)](#) buffer, the errors messages (not implemented yet), and packed dashboard data buffer.

Returns:

The total size of the data packed into the userData field of the status packet.

< TODO: add error reporting strings.

5.9.2.15 void Dashboard::FinalizeArray (void)

Indicate the end of an array packed into the dashboard data structure.

After packing data into the array, call [FinalizeArray\(\)](#). Every call to [AddArray\(\)](#) must have a matching call to [FinalizeArray\(\)](#).

5.9.2.16 void Dashboard::FinalizeCluster (void)

Indicate the end of a cluster packed into the dashboard data structure.

After packing data into the cluster, call [FinalizeCluster\(\)](#). Every call to [AddCluster\(\)](#) must have a matching call to [FinalizeCluster\(\)](#).

5.9.2.17 void Dashboard::Printf (const char * writeFmt, ...)

Print a string to the UserData text on the [Dashboard](#).

This will add text to the buffer to send to the dashboard. You must call [Finalize\(\)](#) periodically to actually send the buffer to the dashboard if you are not using the packed dashboard data.

The documentation for this class was generated from the following files:

- Dashboard.h
- Dashboard.cpp

5.10 DigitalInput Class Reference

```
#include <DigitalInput.h>
```

Inherits [DigitalSource](#).

Public Member Functions

- [DigitalInput](#) (UINT32 channel)
- [DigitalInput](#) (UINT32 slot, UINT32 channel)
- [~DigitalInput](#) ()
- UINT32 [GetChannel](#) ()
- virtual UINT32 [GetChannelForRouting](#) ()
- virtual UINT32 [GetModuleForRouting](#) ()
- virtual bool [GetAnalogTriggerForRouting](#) ()
- virtual void [RequestInterrupts](#) (tInterruptHandler handler)

Asynchronous handler version.

- virtual void [RequestInterrupts](#) ()

Synchronous Wait version.

5.10.1 Detailed Description

Class to read a digital input. This class will read digital inputs and return the current value on the channel. Other devices such as encoders, gear tooth sensors, etc. that are implemented elsewhere will automatically allocate digital inputs and outputs as required. This class is only for devices like switches etc. that aren't implemented anywhere else.

5.10.2 Constructor & Destructor Documentation

5.10.2.1 [DigitalInput::DigitalInput \(UINT32 channel\)](#) [explicit]

Create an instance of a Digital Input class. Creates a digital input given a channel and uses the default module.

5.10.2.2 [DigitalInput::DigitalInput \(UINT32 slot, UINT32 channel\)](#)

Create an instance of a Digital Input class. Creates a digital input given an channel and module.

5.10.2.3 [DigitalInput::~~DigitalInput \(\)](#)

Free resources associated with the Digital Input class.

5.10.3 Member Function Documentation

5.10.3.1 `bool DigitalInput::GetAnalogTriggerForRouting ()` [virtual]

Returns:

The value to be written to the analog trigger field of a routing mux.

Implements [DigitalSource](#).

5.10.3.2 `UINT32 DigitalInput::GetChannel ()`

Returns:

The GPIO channel number that this object represents.

5.10.3.3 `UINT32 DigitalInput::GetChannelForRouting ()` [virtual]

Returns:

The value to be written to the channel field of a routing mux.

Implements [DigitalSource](#).

5.10.3.4 `UINT32 DigitalInput::GetModuleForRouting ()` [virtual]

Returns:

The value to be written to the module field of a routing mux.

Implements [DigitalSource](#).

5.10.3.5 `void DigitalInput::RequestInterrupts ()` [virtual]

Synchronous Wait version.

Request interrupts synchronously on this digital input. Request interrupts in synchronous mode where the user program will have to explicitly wait for the interrupt to occur. The default is interrupt on rising edges only.

Implements [DigitalSource](#).

5.10.3.6 `void DigitalInput::RequestInterrupts (tInterruptHandler handler)` [virtual]

Asynchronous handler version.

Request interrupts asynchronously on this digital input.

Parameters:

handler The address of the interrupt handler function of type `tInterruptHandler` that will be called whenever there is an interrupt on the digital input port. Request interrupts in synchronous mode where the user program interrupt handler will be called when an interrupt occurs. The default is interrupt on rising edges only.

Implements [DigitalSource](#).

The documentation for this class was generated from the following files:

- DigitalInput.h
- DigitalInput.cpp

5.11 DigitalOutput Class Reference

```
#include <DigitalOutput.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [DigitalOutput](#) (UINT32 channel)
- [DigitalOutput](#) (UINT32 slot, UINT32 channel)
- [~DigitalOutput](#) ()
- void [Set](#) (UINT32 value)
- void [Pulse](#) (float length)
- bool [IsPulsing](#) ()

5.11.1 Detailed Description

Class to write to digital outputs. Write values to the digital output channels. Other devices implemented elsewhere will allocate channels automatically so for those devices it shouldn't be done here.

5.11.2 Constructor & Destructor Documentation

5.11.2.1 [DigitalOutput::DigitalOutput \(UINT32 *channel*\)](#) `[explicit]`

Create an instance of a digital output. Create a digital output given a channel. The default module is used.

5.11.2.2 [DigitalOutput::DigitalOutput \(UINT32 *slot*, UINT32 *channel*\)](#)

Create an instance of a digital output. Create an instance of a digital output given a slot and channel.

5.11.2.3 [DigitalOutput::~~DigitalOutput \(\)](#)

Free the resources associated with a digital output.

5.11.3 Member Function Documentation

5.11.3.1 [bool DigitalOutput::IsPulsing \(\)](#)

Determine if the pulse is still going. Determine if a previously started pulse is still going.

5.11.3.2 [void DigitalOutput::Pulse \(float *length*\)](#)

Output a single pulse on the digital output line. Send a single pulse on the digital output line where the pulse duration is specified in seconds. Maximum pulse length is 0.0016 seconds.

Parameters:

length The pulselength in seconds

5.11.3.3 void DigitalOutput::Set (UINT32 *value*)

Set the value of a digital output. Set the value of a digital output to either one (true) or zero (false).

The documentation for this class was generated from the following files:

- DigitalOutput.h
- DigitalOutput.cpp

5.12 DigitalSource Class Reference

```
#include <DigitalSource.h>
```

Inherits InterruptableSensorBase.

Inherited by [AnalogTriggerOutput](#), and [DigitalInput](#).

Public Member Functions

- virtual [~DigitalSource](#) ()

5.12.1 Detailed Description

[DigitalSource](#) Interface. The [DigitalSource](#) represents all the possible inputs for a counter or a quadrature encoder. The source may be either a digital input or an analog input. If the caller just provides a channel, then a digital input will be constructed and freed when finished for the source. The source can either be a digital input or analog trigger but not both.

5.12.2 Constructor & Destructor Documentation

5.12.2.1 [DigitalSource::~~DigitalSource](#) () [virtual]

[DigitalSource](#) destructor.

The documentation for this class was generated from the following files:

- [DigitalSource.h](#)
- [DigitalSource.cpp](#)

5.13 DriverStation Class Reference

```
#include <DriverStation.h>
```

Inherits [SensorBase](#).

Public Member Functions

- float [GetStickAxis](#) (UINT32 stick, UINT32 axis)
- short [GetStickButtons](#) (UINT32 stick)
- float [GetAnalogIn](#) (UINT32 channel)
- bool [GetDigitalIn](#) (UINT32 channel)
- void [SetDigitalOut](#) (UINT32 channel, bool value)
- bool [GetDigitalOut](#) (UINT32 channel)
- UINT32 [GetPacketNumber](#) ()
- float [GetBatteryVoltage](#) ()

Static Public Member Functions

- static [DriverStation](#) * [GetInstance](#) ()

Protected Member Functions

- [DriverStation](#) ()
- void [GetData](#) ()
- void [SetData](#) ()

5.13.1 Detailed Description

Provide access to the network communication data to / from the Driver Station.

5.13.2 Constructor & Destructor Documentation

5.13.2.1 [DriverStation::DriverStation](#) () [protected]

[DriverStation](#) constructor.

This is only called once the first time [GetInstance\(\)](#) is called

5.13.3 Member Function Documentation

5.13.3.1 float [DriverStation::GetAnalogIn](#) (UINT32 *channel*)

Get an analog voltage from the Driver Station. The analog values are returned as UINT32 values for the Driver Station analog inputs. These inputs are typically used for advanced operator interfaces consisting of potentiometers or resistor networks representing values on a rotary switch.

Parameters:

channel The analog input channel on the driver station to read from. Valid range is 1 - 4.

Returns:

The analog voltage on the input.

5.13.3.2 float DriverStation::GetBatteryVoltage ()

Read the battery voltage from the specified [AnalogChannel](#).

This accessor assumes that the battery voltage is being measured through the voltage divider on an analog breakout.

Returns:

The battery voltage.

5.13.3.3 void DriverStation::GetData () [protected]

Copy data from the DS task for the user. If no new data exists, it will just be returned, otherwise the data will be copied from the DS polling loop.

5.13.3.4 bool DriverStation::GetDigitalIn (UINT32 *channel*)

Get values from the digital inputs on the Driver Station. Return digital values from the Drivers Station. These values are typically used for buttons and switches on advanced operator interfaces.

Parameters:

channel The digital input to get. Valid range is 1 - 8.

5.13.3.5 bool DriverStation::GetDigitalOut (UINT32 *channel*)

Get a value that was set for the digital outputs on the Driver Station.

Parameters:

channel The digital output to monitor. Valid range is 1 through 8.

Returns:

A digital value being output on the Drivers Station.

5.13.3.6 DriverStation * DriverStation::GetInstance () [static]

Return a pointer to the singleton [DriverStation](#).

5.13.3.7 UINT32 DriverStation::GetPacketNumber ()

Return the DS packet number. The packet number is the index of this set of data returned by the driver station. Each time new data is received, the packet number (included with the sent data) is returned.

5.13.3.8 float DriverStation::GetStickAxis (UINT32 *stick*, UINT32 *axis*)

Get the value of the axis on a joystick. This depends on the mapping of the joystick connected to the specified port.

Parameters:

- stick* The joystick to read.
- axis* The analog axis value to read from the joystick.

Returns:

The value of the axis on the joystick.

5.13.3.9 short DriverStation::GetStickButtons (UINT32 *stick*)

The state of the buttons on the joystick. 12 buttons (4 msb are unused) from the joystick.

Parameters:

- stick* The joystick to read.

Returns:

The state of the buttons on the joystick.

5.13.3.10 void DriverStation::SetData () [protected]

Copy status data from the DS task for the user. This is used primarily to set digital outputs on the DS.

5.13.3.11 void DriverStation::SetDigitalOut (UINT32 *channel*, bool *value*)

Set a value for the digital outputs on the Driver Station.

Control digital outputs on the Drivers Station. These values are typically used for giving feedback on a custom operator station such as LEDs.

Parameters:

- channel* The digital output to set. Valid range is 1 - 8.
- value* The state to set the digital output.

The documentation for this class was generated from the following files:

- DriverStation.h
- DriverStation.cpp

5.14 Encoder Class Reference

```
#include <Encoder.h>
```

Inherits [SensorBase](#), and [CounterBase](#).

Public Member Functions

- [Encoder](#) (UINT32 aChannel, UINT32 bChannel, bool reverseDirection=false)
- [Encoder](#) (UINT32 aSlot, UINT32 aChannel, UINT32 bSlot, UINT32 _bChannel, bool reverseDirection=false)
- [Encoder](#) ([DigitalSource](#) *aSource, [DigitalSource](#) *bSource, bool reverseDirection=false)
- virtual [~Encoder](#) ()
- void [Start](#) ()
- INT32 [Get](#) ()
- void [Reset](#) ()
- void [Stop](#) ()
- double [GetPeriod](#) ()
- void [SetMaxPeriod](#) (double maxPeriod)
- bool [GetStopped](#) ()
- bool [GetDirection](#) ()
- float [GetDistance](#) ()
- void [SetDistancePerTick](#) (float distancePerTick)
- void [SetReverseDirection](#) (bool reverseDirection)

5.14.1 Detailed Description

Class to read quad encoders. Quadrature encoders are devices that count shaft rotation and can sense direction. The output of the QuadEncoder class is an integer that can count either up or down, and can go negative for reverse direction counting. When creating QuadEncoders, a direction is supplied that changes the sense of the output to make code more readable if the encoder is mounted such that forward movement generates negative values. Quadrature encoders have two digital outputs, an A Channel and a B Channel that are out of phase with each other to allow the FPGA to do direction sensing.

5.14.2 Constructor & Destructor Documentation

5.14.2.1 `Encoder::Encoder (UINT32 aChannel, UINT32 bChannel, bool reverseDirection = false)`

QuadEncoder constructor. Construct a QuadEncoder given a and b channels assuming the default module.

Parameters:

aChannel The a channel digital input channel.

bChannel The b channel digital input channel.

reverseDirection represents the orientation of the encoder and inverts the output values if necessary so forward represents positive values.

5.14.2.2 Encoder::Encoder (UINT32 *aSlot*, UINT32 *aChannel*, UINT32 *bSlot*, UINT32 *bChannel*, bool *reverseDirection* = false)

QuadEncoder constructor. Construct a QuadEncoder given a and b modules and channels fully specified.

Parameters:

aSlot The a channel digital input module.

aChannel The a channel digital input channel.

bSlot The b channel digital input module.

bChannel The b channel digital input channel.

reverseDirection represents the orientation of the encoder and inverts the output values if necessary so forward represents positive values.

5.14.2.3 Encoder::Encoder (DigitalSource * *aSource*, DigitalSource * *bSource*, bool *reverseDirection* = false)

QuadEncoder constructor. Construct a QuadEncoder given a and b channels as digital inputs. This is used in the case where the digital inputs are shared. The QuadEncoder class will not allocate the digital inputs and assume that they already are counted.

Parameters:

aSource The source that should be used for the a channel.

bSource the source that should be used for the b channel.

reverseDirection represents the orientation of the encoder and inverts the output values if necessary so forward represents positive values.

5.14.2.4 Encoder::~~Encoder () [virtual]

Free the resources for a QuadEncoder. Frees the FPGA resources associated with a Quad [Encoder](#).

5.14.3 Member Function Documentation

5.14.3.1 INT32 Encoder::Get () [virtual]

Gets the current count. Returns the current count on the QuadEncoder. Quadrature encoders return 4x the expected number of counts since the hardware counts all 4 edges for higher resolution.

Returns:

Current count from the QuadEncoder.

Implements [CounterBase](#).

5.14.3.2 `bool Encoder::GetDirection ()` [virtual]

The last direction the encoder value changed.

Returns:

The last direction the encoder value changed.

Implements [CounterBase](#).

5.14.3.3 `float Encoder::GetDistance ()`

Get the distance the robot has driven since the last reset

Returns:

The distance driven since the last reset based on the distance per tick variable being set by [SetDistancePerTick\(\)](#). It is just a simple multiplication, but makes the bookkeeping a little easier since the encoder remembers the scale factor.

5.14.3.4 `double Encoder::GetPeriod ()` [virtual]

Returns the period of the most recent pulse. Returns the period of the most recent Quad [Encoder](#) pulse in seconds.

Returns:

Period in seconds of the most recent pulse.

Implements [CounterBase](#).

5.14.3.5 `bool Encoder::GetStopped ()` [virtual]

Determine if the encoder is stopped. Using the MaxPeriod value, a boolean is returned that is true if the encoder is considered stopped and false if it is still moving. A stopped encoder is one where the most recent pulse width exceeds the MaxPeriod.

Returns:

True if the encoder is considered stopped.

Implements [CounterBase](#).

5.14.3.6 `void Encoder::Reset ()` [virtual]

Reset the QuadEncoder to zero. Resets the current count to zero on the encoder.

Implements [CounterBase](#).

5.14.3.7 `void Encoder::SetDistancePerTick (float distancePerTick)`

Set the distance per tick for this encoder. This sets the multiplier used to determine the distance driven based on the count value from the encoder. Resetting the encoder also resets the distance since it's just a simple multiply.

5.14.3.8 void Encoder::SetMaxPeriod (double *maxPeriod*) [virtual]

Sets the maximum period for stopped detection. Sets the value that represents the maximum period of the QuadEncoder before it will assume that the attached device is stopped. This timeout allows users to determine if the wheels or other shaft has stopped rotating.

Parameters:

maxPeriod The maximum time between rising and falling edges before the FPGA will consider the device stopped. This is expressed in seconds.

Implements [CounterBase](#).

5.14.3.9 void Encoder::SetReverseDirection (bool *reverseDirection*)

Set the direction sensing for this encoder. This sets the direction sensing on the encoder so that it could count in the correct software direction regardless of the mounting.

Parameters:

reverseDirection true if the encoder direction should be reversed

5.14.3.10 void Encoder::Start () [virtual]

Start the QuadEncoder. Starts counting pulses on the QuadEncoder device.

Implements [CounterBase](#).

5.14.3.11 void Encoder::Stop () [virtual]

Stops counting pulses on the QuadEncoder device. The value is not changed.

Implements [CounterBase](#).

The documentation for this class was generated from the following files:

- Encoder.h
- Encoder.cpp

5.15 Error Class Reference

```
#include <Error.h>
```

5.15.1 Detailed Description

[Error](#) object represents a library error.

The documentation for this class was generated from the following files:

- Error.h
- Error.cpp

5.16 ErrorBase Class Reference

```
#include <ErrorBase.h>
```

Inherited by [Dashboard](#), [PCVideoServer](#), and [SensorBase](#).

Public Member Functions

- virtual [Error](#) & [GetError](#) ()
Retrieve the current error. Get the current error information associated with this sensor.
- virtual void [SetError](#) (Error::Code code, const char *filename, UINT32 lineNumber) const
Set the current error information associated with this sensor.
- virtual void [ClearError](#) ()
Clear the current error information associated with this sensor.
- virtual bool [StatusIsFatal](#) () const
Check if the current error code represents a fatal error.

Static Public Member Functions

- static [Error](#) & [GetGlobalError](#) ()

Protected Member Functions

- [ErrorBase](#) ()
Initialize the instance status to 0 for now.

5.16.1 Detailed Description

Base class for most objects. [ErrorBase](#) is the base class for most objects since it holds the generated error for that object. In addition, there is a single instance of a global error object

5.16.2 Member Function Documentation

5.16.2.1 [Error](#) & [ErrorBase::GetGlobalError](#) () [static]

Retrieve the current global error.

5.16.2.2 void [ErrorBase::SetError](#) (Error::Code code, const char *filename, UINT32 lineNumber) const [virtual]

Set the current error information associated with this sensor.

Parameters:

- code* The error code
filename Filename of the error source
lineNumber Line number of the error source

5.16.2.3 bool ErrorBase::StatusIsFatal () const [virtual]

Check if the current error code represents a fatal error.

Returns:

true if the current error is fatal.

The documentation for this class was generated from the following files:

- ErrorBase.h
- ErrorBase.cpp

5.17 GearTooth Class Reference

```
#include <GearTooth.h>
```

Inherits [Counter](#).

Public Member Functions

- [GearTooth](#) (UINT32 channel, bool directionSensitive=false)
- [GearTooth](#) (UINT32 slot, UINT32 channel, bool directionSensitive=false)
- [GearTooth](#) ([DigitalSource](#) *source, bool directionSensitive=false)
- virtual [~GearTooth](#) ()
- void [EnableDirectionSensing](#) (bool directionSensitive)

Static Public Attributes

- static const double [kGearToothThreshold](#) = 55e-6
55 uSec for threshold

5.17.1 Detailed Description

Alias for counter class. Implement the gear tooth sensor supplied by FIRST. Currently there is no reverse sensing on the gear tooth sensor, but in future versions we might implement the necessary timing in the FPGA to sense direction.

5.17.2 Constructor & Destructor Documentation

5.17.2.1 [GearTooth::GearTooth](#) (UINT32 *channel*, bool *directionSensitive* = false)

Construct a [GearTooth](#) sensor given a channel.

The default module is assumed.

Parameters:

channel The GPIO channel on the digital module that the sensor is connected to.

directionSensitive Enable the pulse length decoding in hardware to specify count direction.

5.17.2.2 [GearTooth::GearTooth](#) (UINT32 *slot*, UINT32 *channel*, bool *directionSensitive* = false)

Construct a [GearTooth](#) sensor given a channel and module.

Parameters:

slot The slot in the chassis that the digital module is plugged in to.

channel The GPIO channel on the digital module that the sensor is connected to.

directionSensitive Enable the pulse length decoding in hardware to specify count direction.

5.17.2.3 GearTooth::GearTooth (DigitalSource * *source*, bool *directionSensitive* = false)

Construct a [GearTooth](#) sensor given a digital input. This should be used when sharing digital inputs.

Parameters:

source An object that fully describes the input that the sensor is connected to.

directionSensitive Enable the pulse length decoding in hardware to specify count direction.

5.17.2.4 GearTooth::~~GearTooth () [virtual]

Free the resources associated with a gear tooth sensor.

5.17.3 Member Function Documentation

5.17.3.1 void GearTooth::EnableDirectionSensing (bool *directionSensitive*)

Common code called by the constructors.

The documentation for this class was generated from the following files:

- GearTooth.h
- GearTooth.cpp

5.18 GenericHID Class Reference

```
#include <GenericHID.h>
```

Inherited by [Joystick](#).

5.18.1 Detailed Description

[GenericHID](#) Interface

The documentation for this class was generated from the following file:

- [GenericHID.h](#)

5.19 Gyro Class Reference

```
#include <Gyro.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [Gyro](#) (UINT32 slot, UINT32 channel)
- [Gyro](#) (UINT32 channel)
- [Gyro](#) ([AnalogChannel](#) *channel)
- virtual [~Gyro](#) ()
- float [GetAngle](#) ()
- void [SetSensitivity](#) (float voltsPerDegreePerSecond)
- void [Reset](#) ()

5.19.1 Detailed Description

Use a rate gyro to return the robots heading relative to a starting position. The [Gyro](#) class tracks the robots heading based on the starting position. As the robot rotates the new heading is computed by integrating the rate of rotation returned by the sensor. When the class is instantiated, it does a short calibration routine where it samples the gyro while at rest to determine the default offset. This is subtracted from each sample to determine the heading.

5.19.2 Constructor & Destructor Documentation

5.19.2.1 [Gyro::Gyro](#) (UINT32 *slot*, UINT32 *channel*)

[Gyro](#) constructor given a slot and a channel.

Parameters:

slot The cRIO slot for the analog module the gyro is connected to.

channel The analog channel the gyro is connected to.

5.19.2.2 [Gyro::Gyro](#) (UINT32 *channel*) [explicit]

[Gyro](#) constructor with only a channel.

Use the default analog module slot.

Parameters:

channel The analog channel the gyro is connected to.

5.19.2.3 Gyro::Gyro (AnalogChannel * *channel*) [explicit]

[Gyro](#) constructor with a precreated analog channel object. Use this constructor when the analog channel needs to be shared. There is no reference counting when an [AnalogChannel](#) is passed to the gyro.

Parameters:

channel The [AnalogChannel](#) object that the gyro is connected to.

5.19.2.4 Gyro::~~Gyro () [virtual]

Delete (free) the accumulator and the analog components used for the gyro.

5.19.3 Member Function Documentation

5.19.3.1 float Gyro::GetAngle (void)

Return the actual angle in degrees that the robot is currently facing.

The angle is based on the current accumulator value corrected by the oversampling rate, the gyro type and the A/D calibration values. The angle is continuous, that is can go beyond 360 degrees. This make algorithms that wouldn't want to see a discontinuity in the gyro output as it sweeps past 0 on the second time around.

Returns:

the current heading of the robot in degrees. This heading is based on integration of the returned rate from the gyro.

5.19.3.2 void Gyro::Reset ()

Reset the gyro. Resets the gyro to a heading of zero. This can be used if there is significant drift in the gyro and it needs to be recalibrated after it has been running.

5.19.3.3 void Gyro::SetSensitivity (float *voltsPerDegreePerSecond*)

Set the gyro type based on the sensitivity. This takes the number of volts/degree/second sensitivity of the gyro and uses it in subsequent calculations to allow the code to work with multiple gyros.

Parameters:

voltsPerDegreePerSecond The type of gyro specified as the voltage that represents one degree/second.

The documentation for this class was generated from the following files:

- Gyro.h
- Gyro.cpp

5.20 HiTechnicCompass Class Reference

```
#include <HiTechnicCompass.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [HiTechnicCompass](#) (UINT32 slot)
- virtual [~HiTechnicCompass](#) ()
- float [GetAngle](#) ()

5.20.1 Detailed Description

HiTechnic NXT Compass.

This class allows access to a HiTechnic NXT Compass on an [I2C](#) bus. These sensors do not allow changing addresses so you cannot have more than one on a single bus.

Details on the sensor can be found here: <http://www.hitechnic.com/index.html?lang=en-us&target=d17>.

[Todo](#)

Implement a calibration method for the sensor.

5.20.2 Constructor & Destructor Documentation

5.20.2.1 [HiTechnicCompass::HiTechnicCompass \(UINT32 slot\)](#) [[explicit](#)]

Constructor.

Parameters:

slot The slot of the digital module that the sensor is plugged into.

5.20.2.2 [HiTechnicCompass::~~HiTechnicCompass \(\)](#) [[virtual](#)]

Destructor.

5.20.3 Member Function Documentation

5.20.3.1 [float HiTechnicCompass::GetAngle \(\)](#)

Get the compass angle in degrees.

The resolution of this reading is 1 degree.

Returns:

Angle of the compass in degrees.

The documentation for this class was generated from the following files:

- `HiTechnicCompass.h`
- `HiTechnicCompass.cpp`

5.21 I2C Class Reference

```
#include <I2C.h>
```

Inherits [SensorBase](#).

Public Member Functions

- virtual [~I2C](#) ()
- void [Write](#) (UINT8 registerAddress, UINT8 data)
- void [Read](#) (UINT8 registerAddress, UINT8 count, UINT8 *data)
- void [Broadcast](#) (UINT8 registerAddress, UINT8 data)
- bool [VerifySensor](#) (UINT8 registerAddress, UINT8 count, const UINT8 *expected)

5.21.1 Detailed Description

[I2C](#) bus interface class.

This class is intended to be used by sensor (and other [I2C](#) device) drivers. It probably should not be used directly.

It is constructed by calling `DigitalModule::GetI2C()` on a `DigitalModule` object.

5.21.2 Constructor & Destructor Documentation

5.21.2.1 `I2C::~~I2C ()` [virtual]

Destructor.

5.21.3 Member Function Documentation

5.21.3.1 `void I2C::Broadcast (UINT8 registerAddress, UINT8 data)`

Send a broadcast write to all devices on the [I2C](#) bus.

This is not currently implemented!

Parameters:

registerAddress The register to write on all devices on the bus.

data The value to write to the devices.

5.21.3.2 `void I2C::Read (UINT8 registerAddress, UINT8 count, UINT8 *buffer)`

Execute a read transaction with the device.

Read 1, 2, 3, or 4 bytes from a device. Most [I2C](#) devices will auto-increment the register pointer internally allowing you to read up to 4 consecutive registers on a device in a single transaction.

Parameters:

registerAddress The register to read first in the transaction.

count The number of bytes to read in the transaction.

buffer A pointer to the array of bytes to store the data read from the device.

5.21.3.3 **bool I2C::VerifySensor (UINT8 *registerAddress*, UINT8 *count*, const UINT8 * *expected*)**

Verify that a device's registers contain expected values.

Most devices will have a set of registers that contain a known value that can be used to identify them. This allows an [I2C](#) device driver to easily verify that the device contains the expected value.

Precondition:

The device must support and be configured to use register auto-increment.

Parameters:

registerAddress The base register to start reading from the device.

count The size of the field to be verified.

expected A buffer containing the values expected from the device.

5.21.3.4 **void I2C::Write (UINT8 *registerAddress*, UINT8 *data*)**

Execute a write transaction with the device.

Write a byte to a register on a device and wait until the transaction is complete.

Parameters:

registerAddress The address of the register on the device to be written.

data The byte to write to the register on the device.

The documentation for this class was generated from the following files:

- I2C.h
- I2C.cpp

5.22 IterativeRobot Class Reference

```
#include <IterativeRobot.h>
```

Inherits [RobotBase](#).

Public Member Functions

- virtual void [StartCompetition](#) ()
- virtual void [RobotInit](#) ()
- virtual void [DisabledInit](#) ()
- virtual void [AutonomousInit](#) ()
- virtual void [TeleopInit](#) ()
- virtual void [DisabledPeriodic](#) ()
- virtual void [AutonomousPeriodic](#) ()
- virtual void [TeleopPeriodic](#) ()
- virtual void [DisabledContinuous](#) ()
- virtual void [AutonomousContinuous](#) ()
- virtual void [TeleopContinuous](#) ()
- void [SetPeriod](#) (double period)
- double [GetLoopsPerSec](#) ()

Protected Member Functions

- virtual [~IterativeRobot](#) ()
- [IterativeRobot](#) ()

5.22.1 Detailed Description

[IterativeRobot](#) implements a specific type of Robot Program framework, extending the [RobotBase](#) class.

The [IterativeRobot](#) class is intended to be subclassed by a user creating a robot program.

This class is intended to implement the "old style" default code, by providing the following functions which are called by the main loop, [StartCompetition\(\)](#), at the appropriate times:

[RobotInit\(\)](#) – provide for initialization at robot power-on

Init() functions – each of the following functions is called once when the appropriate mode is entered:

- [DisabledInit\(\)](#) – called only when first disabled
- [AutonomousInit\(\)](#) – called each and every time autonomous is entered from another mode
- [TeleopInit\(\)](#) – called each and every time teleop is entered from another mode

Periodic() functions – each of these functions is called iteratively at the appropriate periodic rate (aka the "slow loop"). The default period of the iterative robot is 0.005 seconds, giving a periodic frequency of 200Hz (200 times per second).

- [DisabledPeriodic\(\)](#)
- [AutonomousPeriodic\(\)](#)

- [TeleopPeriodic\(\)](#)

Continuous() functions – each of these functions is called repeatedly as fast as possible:

- [DisabledContinuous\(\)](#)
- [AutonomousContinuous\(\)](#)
- [TeleopContinuous\(\)](#)

5.22.2 Constructor & Destructor Documentation

5.22.2.1 `IterativeRobot::~IterativeRobot ()` [protected, virtual]

Free the resources for a RobotIterativeBase class.

5.22.2.2 `IterativeRobot::IterativeRobot ()` [protected]

Constructor for RobotIterativeBase

The constructor initializes the instance variables for the robot to indicate the status of initialization for disabled, autonomous, and teleop code.

5.22.3 Member Function Documentation

5.22.3.1 `void IterativeRobot::AutonomousContinuous ()` [virtual]

Continuous code for autonomous mode should go here.

Users should override this method for code which will be called repeatedly as frequently as possible while the robot is in autonomous mode.

5.22.3.2 `void IterativeRobot::AutonomousInit ()` [virtual]

Initialization code for autonomous mode should go here.

Users should override this method for initialization code which will be called each time the robot enters autonomous mode.

5.22.3.3 `void IterativeRobot::AutonomousPeriodic ()` [virtual]

Periodic code for autonomous mode should go here.

Users should override this method for code which will be called periodically at a regular rate while the robot is in autonomous mode.

5.22.3.4 `void IterativeRobot::DisabledContinuous ()` [virtual]

Continuous code for disabled mode should go here.

Users should override this method for code which will be called repeatedly as frequently as possible while the robot is in disabled mode.

5.22.3.5 void IterativeRobot::DisabledInit () [virtual]

Initialization code for disabled mode should go here.

Users should override this method for initialization code which will be called each time the robot enters disabled mode.

5.22.3.6 void IterativeRobot::DisabledPeriodic () [virtual]

Periodic code for disabled mode should go here.

Users should override this method for code which will be called periodically at a regular rate while the robot is in disabled mode.

5.22.3.7 double IterativeRobot::GetLoopsPerSec ()

Get the number of loops per second for the [IterativeRobot](#)

Get the number of loops per second for the [IterativeRobot](#). The default period of 0.005 seconds results in 200 loops per second. (200Hz iteration loop).

5.22.3.8 void IterativeRobot::RobotInit () [virtual]

Robot-wide initialization code should go here.

Users should override this method for default Robot-wide initialization which will be called when the robot is first powered on. It will be called exactly 1 time.

5.22.3.9 void IterativeRobot::SetPeriod (double *period*)

Set the period for the periodic functions.

The period is set in seconds for the length of time between calls to the periodic functions. Default period is 0.005 seconds (200Hz iteration loop).

5.22.3.10 void IterativeRobot::StartCompetition () [virtual]

default period for periodic functions

Provide an alternate "main loop" via [StartCompetition\(\)](#).

This specific [StartCompetition\(\)](#) implements "main loop" behavior like that of the FRC control system in 2008 and earlier, with a primary (slow) loop that is called periodically, and a "fast loop" (a.k.a. "spin loop") that is called as fast as possible with no delay between calls.

Implements [RobotBase](#).

5.22.3.11 void IterativeRobot::TeleopContinuous () [virtual]

Continuous code for teleop mode should go here.

Users should override this method for code which will be called repeatedly as frequently as possible while the robot is in teleop mode.

5.22.3.12 void IterativeRobot::TeleopInit () [virtual]

Initialization code for teleop mode should go here.

Users should override this method for initialization code which will be called each time the robot enters teleop mode.

5.22.3.13 void IterativeRobot::TeleopPeriodic () [virtual]

Periodic code for teleop mode should go here.

Users should override this method for code which will be called periodically at a regular rate while the robot is in teleop mode.

The documentation for this class was generated from the following files:

- IterativeRobot.h
- IterativeRobot.cpp

5.23 Jaguar Class Reference

```
#include <Jaguar.h>
```

Inherits [PWM](#), and [SpeedController](#).

Public Member Functions

- [Jaguar](#) (UINT32 channel)
- [Jaguar](#) (UINT32 slot, UINT32 channel)
- float [Get](#) ()
- void [Set](#) (float value)

5.23.1 Detailed Description

Luminary Micro [Jaguar](#) Speed Control

5.23.2 Constructor & Destructor Documentation

5.23.2.1 [Jaguar::Jaguar \(UINT32 *channel*\)](#) [explicit]

Constructor that assumes the default digital module.

Parameters:

channel The [PWM](#) channel on the digital module that the [Jaguar](#) is attached to.

5.23.2.2 [Jaguar::Jaguar \(UINT32 *slot*, UINT32 *channel*\)](#)

Constructor that specifies the digital module.

Parameters:

slot The slot in the chassis that the digital module is plugged into.

channel The [PWM](#) channel on the digital module that the [Jaguar](#) is attached to.

5.23.3 Member Function Documentation

5.23.3.1 [float Jaguar::Get \(\)](#) [virtual]

Get the recently set value of the [PWM](#).

Returns:

The most recently set value for the [PWM](#) between -1.0 and 1.0.

Implements [SpeedController](#).

5.23.3.2 void Jaguar::Set (float *speed*) [virtual]

Set the [PWM](#) value.

The [PWM](#) value is set using a range of -1.0 to 1.0, appropriately scaling the value for the FPGA.

Parameters:

speed The speed value between -1.0 and 1.0 to set.

Implements [SpeedController](#).

The documentation for this class was generated from the following files:

- Jaguar.h
- Jaguar.cpp

5.24 Joystick Class Reference

```
#include <Joystick.h>
```

Inherits [GenericHID](#).

Public Member Functions

- [Joystick](#) (UINT32 port)
- [Joystick](#) (UINT32 port, UINT32 numAxisTypes, UINT32 numButtonTypes)
- UINT32 [GetAxisChannel](#) (AxisType axis)
- void [SetAxisChannel](#) (AxisType axis, UINT32 channel)
- virtual float [GetX](#) (JoystickHand hand=kRightHand)
- virtual float [GetY](#) (JoystickHand hand=kRightHand)
- virtual float [GetZ](#) ()
- virtual float [GetTwist](#) ()
- virtual float [GetThrottle](#) ()
- virtual float [GetAxis](#) (AxisType axis)
- float [GetRawAxis](#) (UINT32 axis)
- virtual bool [GetTrigger](#) (JoystickHand hand=kRightHand)
- virtual bool [GetTop](#) (JoystickHand hand=kRightHand)
- virtual bool [GetBumper](#) (JoystickHand hand=kRightHand)
- virtual bool [GetButton](#) (ButtonType button)
- bool [GetRawButton](#) (UINT32 button)

5.24.1 Detailed Description

Handle input from standard Joysticks connected to the Driver Station. This class handles standard input that comes from the Driver Station. Each time a value is requested the most recent value is returned. There is a single class instance for each joystick and the mapping of ports to hardware buttons depends on the code in the driver station.

5.24.2 Constructor & Destructor Documentation

5.24.2.1 Joystick::Joystick (UINT32 *port*) [explicit]

Construct an instance of a joystick. The joystick index is the usb port on the drivers station.

Parameters:

port The port on the driver station that the joystick is plugged into.

5.24.2.2 Joystick::Joystick (UINT32 *port*, UINT32 *numAxisTypes*, UINT32 *numButtonTypes*)

Version of the constructor to be called by sub-classes.

This constructor allows the subclass to configure the number of constants for axes and buttons.

Parameters:

port The port on the driver station that the joystick is plugged into.

numAxisTypes The number of axis types in the enum.

numButtonTypes The number of button types in the enum.

5.24.3 Member Function Documentation

5.24.3.1 float Joystick::GetAxis (AxisType *axis*) [virtual]

For the current joystick, return the axis determined by the argument.

This is for cases where the joystick axis is returned programatically, otherwise one of the previous functions would be preferable (for example [GetX\(\)](#)).

Parameters:

axis The axis to read.

Returns:

The value of the axis.

5.24.3.2 UINT32 Joystick::GetAxisChannel (AxisType *axis*)

Get the channel currently associated with the specified axis.

Parameters:

axis The axis to look up the channel for.

Returns:

The channel fr the axis.

5.24.3.3 bool Joystick::GetBumper (JoystickHand *hand* = kRightHand) [virtual]

This is not supported for the [Joystick](#). This method is only here to complete the [GenericHID](#) interface.

Implements [GenericHID](#).

5.24.3.4 bool Joystick::GetButton (ButtonType *button*) [virtual]

Get buttons based on an enumerated type.

The button type will be looked up in the list of buttons and then read.

Parameters:

button The type of button to read.

Returns:

The state of the button.

5.24.3.5 float Joystick::GetRawAxis (UINT32 *axis*) [virtual]

Get the value of the axis.

Parameters:

axis The axis to read [1-6].

Returns:

The value of the axis.

Implements [GenericHID](#).

5.24.3.6 bool Joystick::GetRawButton (UINT32 *button*) [virtual]

Get the button value for buttons 1 through 12.

The buttons are returned in a single 16 bit value with one bit representing the state of each button. The appropriate button is returned as a boolean value.

Parameters:

button The button number to be read.

Returns:

The state of the button.

Implements [GenericHID](#).

5.24.3.7 float Joystick::GetThrottle () [virtual]

Get the throttle value of the current joystick. This depends on the mapping of the joystick connected to the current port.

Implements [GenericHID](#).

5.24.3.8 bool Joystick::GetTop (JoystickHand *hand* = kRightHand) [virtual]

Read the state of the top button on the joystick.

Look up which button has been assigned to the top and read its state.

Parameters:

hand This parameter is ignored for the [Joystick](#) class and is only here to complete the [GenericHID](#) interface.

Returns:

The state of the top button.

Implements [GenericHID](#).

5.24.3.9 bool Joystick::GetTrigger (JoystickHand *hand* = kRightHand) [virtual]

Read the state of the trigger on the joystick.

Look up which button has been assigned to the trigger and read its state.

Parameters:

hand This parameter is ignored for the [Joystick](#) class and is only here to complete the [GenericHID](#) interface.

Returns:

The state of the trigger.

Implements [GenericHID](#).

5.24.3.10 float Joystick::GetTwist () [virtual]

Get the twist value of the current joystick. This depends on the mapping of the joystick connected to the current port.

Implements [GenericHID](#).

5.24.3.11 float Joystick::GetX (JoystickHand *hand* = kRightHand) [virtual]

Get the X value of the joystick. This depends on the mapping of the joystick connected to the current port.

Implements [GenericHID](#).

5.24.3.12 float Joystick::GetY (JoystickHand *hand* = kRightHand) [virtual]

Get the Y value of the joystick. This depends on the mapping of the joystick connected to the current port.

Implements [GenericHID](#).

5.24.3.13 float Joystick::GetZ () [virtual]

Get the Z value of the current joystick. This depends on the mapping of the joystick connected to the current port.

Implements [GenericHID](#).

5.24.3.14 void Joystick::SetAxisChannel (AxisType *axis*, UINT32 *channel*)

Set the channel associated with a specified axis.

Parameters:

axis The axis to set the channel for.

channel The channel to set the axis to.

The documentation for this class was generated from the following files:

- Joystick.h
- Joystick.cpp

5.25 ParticleAnalysisReport_struct Struct Reference

```
#include <VisionAPI.h>
```

5.25.1 Detailed Description

frcParticleAnalysis returns this structure

The documentation for this struct was generated from the following file:

- VisionAPI.h

5.26 PCVideoServer Class Reference

```
#include <PCVideoServer.h>
```

Inherits [ErrorBase](#).

Public Member Functions

- [PCVideoServer](#) (void)
Constructor.
- [~PCVideoServer](#) ()
Destructor. Stop serving images and destroy this class.
- void [Start](#) ()
Start sending images to the PC.
- void [Stop](#) ()
Stop sending images to the PC.

5.26.1 Detailed Description

Class the serves images to the PC.

The documentation for this class was generated from the following files:

- PCVideoServer.h
- PCVideoServer.cpp

5.27 PIDController Class Reference

```
#include <PIDController.h>
```

Public Member Functions

- [PIDController](#) (float p, float i, float d, float period=0.05)
- [~PIDController](#) ()
- float [Get](#) ()
- void [SetContinuous](#) (bool continuous=true)
- void [SetInput](#) (PIDSource *pidInput)
- void [SetInput](#) (PIDSource *pidInput, float minimumInput, float maximumInput)
- void [SetOutput](#) (PIDOutput *pidOutput)
- void [SetOutput](#) (PIDOutput *pidOutput, float minimumOutput, float maximumOutput)
- void [SetSetpoint](#) (float setpoint)
- float [GetSetpoint](#) ()
- float [GetError](#) ()
- void [Enable](#) ()
- void [Disable](#) ()
- void [Reset](#) ()

5.27.1 Detailed Description

Class implements a PID Control Loop.

Creates a separate thread which reads the given [PIDSource](#) and takes care of the integral calculations, as well as writing the given [PIDOutput](#)

5.27.2 Constructor & Destructor Documentation

5.27.2.1 PIDController::PIDController (float *Kp*, float *Ki*, float *Kd*, float *period* = 0.05)

Allocate a PID object with the given constants for P, I, D

Parameters:

Kp the proportional coefficient

Ki the integral coefficient

Kd the derivative coefficient

period the loop time for doing calculations. This particularly effects calculations of the integral and differential terms. The default is 50ms.

5.27.2.2 PIDController::~~PIDController ()

Free the PID object

5.27.3 Member Function Documentation

5.27.3.1 void PIDController::Disable ()

Stop running the [PIDController](#), this sets the output to zero before stopping.

5.27.3.2 void PIDController::Enable ()

Begin running the [PIDController](#)

5.27.3.3 float PIDController::Get ()

Return the current PID result This is always centered on zero and constrained the the max and min outs

Returns:

the latest calculated output

5.27.3.4 float PIDController::GetError ()

Retruns the current difference of the input from the setpoint

Returns:

the current error

5.27.3.5 float PIDController::GetSetpoint ()

Returns the current setpoint of the [PIDController](#)

Returns:

the current setpoint

5.27.3.6 void PIDController::Reset ()

Reset the previous error,, the integral term, and disable the controller.

5.27.3.7 void PIDController::SetContinuous (bool *continuous* = true)

Set the PID controller to consider the input to be continuous, Rather then using the max and min in as constraints, it considers them to be the same point and automatically calculates the shortest route to the setpoint.

Parameters:

continuous Set to true turns on continuous, false turns off continuous

5.27.3.8 void `PIDController::SetInput` (`PIDSource * pidInput`, float *minimumInput*, float *maximumInput*)

Sets the [PIDSource](#) object from which the [PIDController](#) gets its feedback, as well as the maximum and minimum values expected from the input.

Parameters:

pidInput the source of feedback for the [PIDController](#)
minimumInput the minimum value expected from the input
maximumInput the maximum value expected from the output

5.27.3.9 void `PIDController::SetInput` (`PIDSource * pidInput`)

Sets the [PIDSource](#) object from which the [PIDController](#) gets its feedback.

Parameters:

pidInput the source of feedback for the [PIDController](#)

5.27.3.10 void `PIDController::SetOutput` (`PIDOutput * pidOutput`, float *minimumOutput*, float *maximumOutput*)

Sets the [PIDOutput](#) object which the [PIDController](#) writes to, as well as the minimum and maximum values to write.

Parameters:

pidOutput the source of feedback for the [PIDController](#)
minimumOutput the minimum value to write to the output
maximumOutput the maximum value to write to the output

5.27.3.11 void `PIDController::SetOutput` (`PIDOutput * pidOutput`)

Sets the [PIDOutput](#) object which the [PIDController](#) writes to.

Parameters:

pidOutput the source of feedback for the [PIDController](#)

5.27.3.12 void `PIDController::SetSetpoint` (float *setpoint*)

Set the setpoint for the [PIDController](#)

Parameters:

setpoint the desired setpoint

The documentation for this class was generated from the following files:

- `PIDController.h`
- `PIDController.cpp`

5.28 PIDOutput Class Reference

```
#include <PIDOutput.h>
```

5.28.1 Detailed Description

[PIDOutput](#) interface is a generic output for the PID class. PWMs use this class. Users implement this interface to allow for a [PIDController](#) to read directly from the inputs

The documentation for this class was generated from the following file:

- [PIDOutput.h](#)

5.29 PIDSource Class Reference

```
#include <PIDSource.h>
```

5.29.1 Detailed Description

[PIDSource](#) interface is a generic sensor source for the PID class. All sensors that can be used with the PID class will implement the [PIDSource](#) that returns a standard value that will be used in the PID code.

The documentation for this class was generated from the following file:

- PIDSource.h

5.30 PWM Class Reference

```
#include <PWM.h>
```

Inherits [SensorBase](#).

Inherited by [Jaguar](#), [Servo](#), and [Victor](#).

Public Member Functions

- [PWM](#) (UINT32 channel)
- [PWM](#) (UINT32 slot, UINT32 channel)
- virtual [~PWM](#) ()
- void [SetRaw](#) (UINT8 value)
- UINT8 [GetRaw](#) ()
- void [SetPeriodMultiplier](#) (PeriodMultiplier mult)
- void [EnableDeadbandElimination](#) (bool eliminateDeadband)
- void [SetBounds](#) (INT32 max, INT32 deadbandMax, INT32 center, INT32 deadbandMin, INT32 min)

Protected Member Functions

- void [SetPosition](#) (float pos)
- float [GetPosition](#) ()
- void [SetSpeed](#) (float speed)
- float [GetSpeed](#) ()

Static Protected Attributes

- static const UINT32 [kDefaultPwmPeriod](#) = 774
- static const UINT32 [kDefaultMinPwmHigh](#) = 102

5.30.1 Detailed Description

Class implements the [PWM](#) generation in the FPGA.

The values supplied as arguments for [PWM](#) outputs range from -1.0 to 1.0. They are mapped to the hardware dependent values, in this case 0-255 for the FPGA. Changes are immediately sent to the FPGA, and the update occurs at the next FPGA cycle. There is no delay.

As of revision 0.1.10 of the FPGA, the FPGA interprets the 0-255 values as follows:

- 255 = full "forward"
- 254 to 129 = linear scaling from "full forward" to "center"
- 128 = center value
- 127 to 2 = linear scaling from "center" to "full reverse"
- 1 = full "reverse"
- 0 = disabled (i.e. [PWM](#) output is held low)

5.30.2 Constructor & Destructor Documentation

5.30.2.1 PWM::PWM (UINT32 *channel*) [explicit]

Allocate a [PWM](#) in the default module given a channel.

Using a default module allocate a [PWM](#) given the channel number. The default module is the first slot numerically in the cRIO chassis.

Parameters:

channel The [PWM](#) channel on the digital module.

5.30.2.2 PWM::PWM (UINT32 *slot*, UINT32 *channel*)

Allocate a [PWM](#) given a module and channel. Allocate a [PWM](#) using a module and channel number.

Parameters:

slot The slot the digital module is plugged into.

channel The [PWM](#) channel on the digital module.

5.30.2.3 PWM::~~PWM () [virtual]

Free the [PWM](#) channel.

Free the resource associated with the [PWM](#) channel and set the value to 0.

5.30.3 Member Function Documentation

5.30.3.1 void PWM::EnableDeadbandElimination (bool *eliminateDeadband*)

Optionally eliminate the deadband from a speed controller.

Parameters:

eliminateDeadband If true, set the motor curve on the [Jaguar](#) to eliminate the deadband in the middle of the range. Otherwise, keep the full range without modifying any values.

5.30.3.2 float PWM::GetPosition () [protected]

Get the [PWM](#) value in terms of a position.

This is intended to be used by servos.

Precondition:

SetMaxPositivePwm() called.

SetMinNegativePwm() called.

Returns:

The position the servo is set to between 0.0 and 1.0.

5.30.3.3 UINT8 PWM::GetRaw ()

Get the [PWM](#) value directly from the hardware.

Read a raw value from a [PWM](#) channel.

Returns:

Raw [PWM](#) control value. Range: 0 - 255.

5.30.3.4 float PWM::GetSpeed () [protected]

Get the [PWM](#) value in terms of speed.

This is intended to be used by speed controllers.

Precondition:

SetMaxPositivePwm() called.

SetMinPositivePwm() called.

SetMaxNegativePwm() called.

SetMinNegativePwm() called.

Returns:

The most recently set speed between -1.0 and 1.0.

5.30.3.5 void PWM::SetBounds (INT32 *max*, INT32 *deadbandMax*, INT32 *center*, INT32 *deadbandMin*, INT32 *min*)

Set the bounds on the [PWM](#) values. This sets the bounds on the [PWM](#) values for a particular each type of controller. The values determine the upper and lower speeds as well as the deadband bracket.

Parameters:

max The Minimum pwm value

deadbandMax The high end of the deadband range

center The center speed (off)

deadbandMin The low end of the deadband range

min The minimum pwm value

5.30.3.6 void PWM::SetPeriodMultiplier (PeriodMultiplier *mult*)

Slow down the [PWM](#) signal for old devices.

Parameters:

mult The period multiplier to apply to this channel

5.30.3.7 void PWM::SetPosition (float *pos*) [protected]

Set the [PWM](#) value based on a position.

This is intended to be used by servos.

Precondition:

SetMaxPositivePwm() called.
SetMinNegativePwm() called.

Parameters:

pos The position to set the servo between 0.0 and 1.0.

5.30.3.8 void PWM::SetRaw (UINT8 *value*)

Set the [PWM](#) value directly to the hardware.

Write a raw value to a [PWM](#) channel.

Parameters:

value Raw [PWM](#) value. Range 0 - 255.

5.30.3.9 void PWM::SetSpeed (float *speed*) [protected]

Set the [PWM](#) value based on a speed.

This is intended to be used by speed controllers.

Precondition:

SetMaxPositivePwm() called.
SetMinPositivePwm() called.
SetCenterPwm() called.
SetMaxNegativePwm() called.
SetMinNegativePwm() called.

Parameters:

speed The speed to set the speed controller between -1.0 and 1.0.

5.30.4 Member Data Documentation

5.30.4.1 const UINT32 PWM::kDefaultMinPwmHigh = 102 [static, protected]

kDefaultMinPwmHigh is "ticks" where each tick is 6.525us

- There are 128 pwm values less than the center, so...
- The minimum output pulse length is $1.5\text{ms} - 128 * 6.525\text{us} = 0.665\text{ms}$
- $0.665\text{ms} / 6.525\text{us}$ per tick = 102

5.30.4.2 `const UINT32 PWM::kDefaultPwmPeriod = 774` `[static, protected]`

`kDefaultPwmPeriod` is "ticks" where each tick is 6.525us

- 20ms periods (50 Hz) are the "safest" setting in that this works for all devices
- 20ms periods seem to be desirable for Vex Motors
- 20ms periods are the specified period for HS-322HD servos, but work reliably down to 10.0 ms; starting at about 8.5ms, the servo sometimes hums and get hot; by 5.0ms the hum is nearly continuous
- 10ms periods work well for [Victor 884](#)
- 5ms periods allows higher update rates for Luminary Micro [Jaguar](#) speed controllers. Due to the shipping firmware on the [Jaguar](#), we can't run the update period less than 5.05 ms.

`kDefaultPwmPeriod` is the 1x period (5.05 ms). In hardware, the period scaling is implemented as an output squelch to get longer periods for old devices.

Set to 5.05 ms period / 6.525us clock = 774

The documentation for this class was generated from the following files:

- PWM.h
- PWM.cpp

5.31 Relay Class Reference

```
#include <Relay.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [Relay](#) (UINT32 channel, Direction direction=kBothDirections)
- [Relay](#) (UINT32 slot, UINT32 channel, Direction direction=kBothDirections)
- virtual [~Relay](#) ()
- void [Set](#) (Value value)

5.31.1 Detailed Description

Class for Spike style relay outputs. Relays are intended to be connected to spikes or similar relays. The relay channels controls a pair of pins that are either both off, one on, the other on, or both on. This translates into two spike outputs at 0v, one at 12v and one at 0v, one at 0v and the other at 12v, or two spike outputs at 12V. This allows off, full forward, or full reverse control of motors without variable speed. It also allows the two channels (forward and reverse) to be used independently for something that does not care about voltage polarity (like a solenoid).

5.31.2 Constructor & Destructor Documentation

5.31.2.1 [Relay::Relay](#) (UINT32 *channel*, [Relay::Direction](#) *direction* = kBothDirections)

[Relay](#) constructor given a channel only where the default digital module is used.

Parameters:

channel The channel number within the default module for this relay.

direction The direction that the [Relay](#) object will control.

5.31.2.2 [Relay::Relay](#) (UINT32 *slot*, UINT32 *channel*, [Relay::Direction](#) *direction* = kBothDirections)

[Relay](#) constructor given the module and the channel.

Parameters:

slot The module slot number this relay is connected to.

channel The channel number within the module for this relay.

direction The direction that the [Relay](#) object will control.

5.31.2.3 [Relay::~~Relay](#) () [virtual]

Free the resource associated with a relay. The relay channels are set to free and the relay output is turned off.

5.31.3 Member Function Documentation

5.31.3.1 void Relay::Set (Relay::Value *value*)

Set the relay state.

Valid values depend on which directions of the relay are controlled by the object.

When set to `kBothDirections`, the relay can only be one of the three reasonable values, `0v-0v`, `0v-12v`, or `12v-0v`.

When set to `kForwardOnly` or `kReverseOnly`, you can specify the constant for the direction or you can simply specify `kOff` and `kOn`. Using only `kOff` and `kOn` is recommended.

Parameters:

value The state to set the relay.

The documentation for this class was generated from the following files:

- Relay.h
- Relay.cpp

5.32 Resource Class Reference

```
#include <Resource.h>
```

Public Member Functions

- virtual [~Resource](#) ()
- UINT32 [Allocate](#) ()
- UINT32 [Allocate](#) (UINT32 index)
- void [Free](#) (UINT32 index)

Protected Member Functions

- [Resource](#) (UINT32 size)

5.32.1 Detailed Description

Track resources in the program. The [Resource](#) class is a convenient way of keeping track of allocated arbitrary resources in the program. Resources are just indices that have an lower and upper bound that are tracked by this class. In the library they are used for tracking allocation of hardware channels but this is purely arbitrary. The resource class does not do any actual allocation, but simply tracks if a given index is currently in use.

WARNING: this should only be statically allocated. When the program loads into memory all the static constructors are called. At that time a linked list of all the "Resources" is created. Then when the program actually starts - in the Robot constructor, all resources are initialized. This ensures that the program is restartable in memory without having to unload/reload.

5.32.2 Constructor & Destructor Documentation

5.32.2.1 [Resource::~~Resource](#) () [virtual]

Delete the allocated array or resources. This happens when the module is unloaded (provided it was statically allocated).

5.32.2.2 [Resource::Resource](#) (UINT32 *elements*) [explicit, protected]

Allocate storage for a new instance of [Resource](#). Allocate a bool array of values that will get initialized to indicate that no resources have been allocated yet. The indices of the resources are 0..size-1.

5.32.3 Member Function Documentation

5.32.3.1 [UINT32 Resource::Allocate](#) (UINT32 *index*)

Allocate a specific resource value. The user requests a specific resource value, i.e. channel number and it is verified unallocated, then returned.

5.32.3.2 `UINT32 Resource::Allocate ()`

Allocate a resource. When a resource is requested, mark it allocated. In this case, a free resource value within the range is located and returned after it is marked allocated.

5.32.3.3 `void Resource::Free (UINT32 index)`

Free an allocated resource. After a resource is no longer needed, for example a destructor is called for a channel assignment class, Free will release the resource value so it can be reused somewhere else in the program.

The documentation for this class was generated from the following files:

- Resource.h
- Resource.cpp

5.33 RobotBase Class Reference

```
#include <RobotBase.h>
```

Inherited by [IterativeRobot](#), and [SimpleRobot](#).

Public Member Functions

- bool [IsDisabled](#) ()
- bool [IsAutonomous](#) ()
- bool [IsOperatorControl](#) ()
- bool [IsSystemActive](#) ()
- bool [IsNewDataAvailable](#) ()
- [Watchdog](#) & [GetWatchdog](#) ()

Static Public Member Functions

- static void [startRobotTask](#) (FUNCPTR factory)
- static void [robotTask](#) (FUNCPTR factory, [Task](#) *task)

Protected Member Functions

- virtual [~RobotBase](#) ()
- [RobotBase](#) ()

Friends

- class [RobotDeleter](#)

5.33.1 Detailed Description

Implement a Robot Program framework. The [RobotBase](#) class is intended to be subclassed by a user creating a robot program. Overridden [Autonomous\(\)](#) and [OperatorControl\(\)](#) methods are called at the appropriate time as the match proceeds. In the current implementation, the Autonomous code will run to completion before the OperatorControl code could start. In the future the Autonomous code might be spawned as a task, then killed at the end of the Autonomous period.

5.33.2 Constructor & Destructor Documentation

5.33.2.1 [RobotBase::~RobotBase](#) () [protected, virtual]

Free the resources for a [RobotBase](#) class. This includes deleting all classes that might have been allocated as Singletons so they would never be deleted except here.

5.33.2.2 RobotBase::RobotBase () [protected]

Constructor for a generic robot program. User code should be placed in the constructor that runs before the Autonomous or Operator Control period starts. The constructor will run to completion before Autonomous is entered.

This must be used to ensure that the communications code starts. In the future it would be nice to put this code into it's own task that loads on boot so ensure that it runs.

5.33.3 Member Function Documentation

5.33.3.1 Watchdog & RobotBase::GetWatchdog ()

Return the instance of the [Watchdog](#) timer. Get the watchdog timer so the user program can either disable it or feed it when necessary.

5.33.3.2 bool RobotBase::IsAutonomous ()

Determine if the robot is currently in Autonomous mode.

Returns:

True if the robot is currently operating Autonomously as determined by the field controls.

5.33.3.3 bool RobotBase::IsDisabled ()

Determine if the Robot is currently disabled.

Returns:

True if the Robot is currently disabled by the field controls.

5.33.3.4 bool RobotBase::IsNewDataAvailable ()

Indicates if new data is available from the driver station.

Todo

The current implementation is silly. We already know this explicitly without trying to figure it out.

Returns:

Has new data arrived over the network since the last time this function was called?

5.33.3.5 bool RobotBase::IsOperatorControl ()

Determine if the robot is currently in Operator Control mode.

Returns:

True if the robot is currently operating in Tele-Op mode as determined by the field controls.

5.33.3.6 **bool RobotBase::IsSystemActive ()**

Check on the overall status of the system.

Returns:

Is the system active (i.e. [PWM](#) motor outputs, etc. enabled)?

5.33.3.7 **void RobotBase::robotTask (FUNCPTR *factory*, Task * *task*) [static]**

Static interface that will start the competition in the new task.

5.33.3.8 **void RobotBase::startRobotTask (FUNCPTR *factory*) [static]**

Start the robot code. This function starts the robot code running by spawning a task. Currently tasks seemed to be started by LVRT without setting the VX_FP_TASK flag so floating point context is not saved on interrupts. Therefore the program experiences hard to debug and unpredictable results. So the LVRT code starts this function, and it, in turn, starts the actual user program.

The documentation for this class was generated from the following files:

- RobotBase.h
- RobotBase.cpp

5.34 RobotDeleter Class Reference

5.34.1 Detailed Description

This class exists for the sole purpose of getting its destructor called when the module unloads. Before the module is done unloading, we need to delete the [RobotBase](#) derived singleton. This should delete the other remaining singletons that were registered. This should also stop all tasks that are using the [Task](#) class.

The documentation for this class was generated from the following file:

- RobotBase.cpp

5.35 RobotDrive Class Reference

```
#include <RobotDrive.h>
```

Public Member Functions

- [RobotDrive](#) (UINT32 leftMotorChannel, UINT32 rightMotorChannel, float sensitivity=0.5)
- [RobotDrive](#) (UINT32 frontLeftMotorChannel, UINT32 rearLeftMotorChannel, UINT32 frontRightMotorChannel, UINT32 rearRightMotorChannel, float sensitivity=0.5)
- [RobotDrive](#) ([SpeedController](#) *leftMotor, [SpeedController](#) *rightMotor, float sensitivity=0.5)
- [RobotDrive](#) ([SpeedController](#) *frontLeftMotor, [SpeedController](#) *rearLeftMotor, [SpeedController](#) *frontRightMotor, [SpeedController](#) *rearRightMotor, float sensitivity=0.5)
- virtual [~RobotDrive](#) ()
- void [Drive](#) (float speed, float curve)
- void [TankDrive](#) ([GenericHID](#) *leftStick, [GenericHID](#) *rightStick)
- void [TankDrive](#) ([GenericHID](#) *leftStick, UINT32 leftAxis, [GenericHID](#) *rightStick, UINT32 rightAxis)
- void [TankDrive](#) (float leftValue, float rightValue)
- void [ArcadeDrive](#) ([GenericHID](#) *stick, bool squaredInputs=true)
- void [ArcadeDrive](#) ([GenericHID](#) &stick, bool squaredInputs=true)
- void [ArcadeDrive](#) ([GenericHID](#) *moveStick, UINT32 moveChannel, [GenericHID](#) *rotateStick, UINT32 rotateChannel, bool squaredInputs=true)
- void [ArcadeDrive](#) ([GenericHID](#) &moveStick, UINT32 moveChannel, [GenericHID](#) &rotateStick, UINT32 rotateChannel, bool squaredInputs=true)
- void [ArcadeDrive](#) (float moveValue, float rotateValue, bool squaredInputs=true)
- void [HolonomicDrive](#) (float magnitude, float direction, float rotation)
- void [SetLeftRightMotorSpeeds](#) (float leftSpeed, float rightSpeed)

5.35.1 Detailed Description

Utility class for handling Robot drive based on a definition of the motor configuration. The robot drive class handles basic driving for a robot. Currently, 2 and 4 motor standard drive trains are supported. In the future other drive types like swerve and meccanum might be implemented. Motor channel numbers are passed supplied on creation of the class. Those are used for either the Drive function (intended for hand created drive code, such as autonomous) or with the Tank/Arcade functions intended to be used for Operator Control driving.

5.35.2 Constructor & Destructor Documentation

5.35.2.1 [RobotDrive::RobotDrive](#) (UINT32 *leftMotorChannel*, UINT32 *rightMotorChannel*, float *sensitivity* = 0.5)

Constructor for [RobotDrive](#) with 2 motors specified with channel numbers. Set up parameters for a two wheel drive system where the left and right motor pwm channels are specified in the call. This call assumes Jaguars for controlling the motors.

Parameters:

leftMotorChannel The [PWM](#) channel number on the default digital module that drives the left motor.

rightMotorChannel The [PWM](#) channel number on the default digital module that drives the right motor.

sensitivity Effectively sets the turning sensitivity (or turn radius for a given value).

5.35.2.2 RobotDrive::RobotDrive (UINT32 *frontLeftMotor*, UINT32 *rearLeftMotor*, UINT32 *frontRightMotor*, UINT32 *rearRightMotor*, float *sensitivity* = 0.5)

Constructor for [RobotDrive](#) with 4 motors specified with channel numbers. Set up parameters for a four wheel drive system where all four motor pwm channels are specified in the call. This call assumes Jaguars for controlling the motors.

Parameters:

frontLeftMotor Front left motor channel number on the default digital module

rearLeftMotor Rear Left motor channel number on the default digital module

frontRightMotor Front right motor channel number on the default digital module

rearRightMotor Rear Right motor channel number on the default digital module

sensitivity Effectively sets the turning sensitivity (or turn radius for a given value)

5.35.2.3 RobotDrive::RobotDrive (SpeedController * *leftMotor*, SpeedController * *rightMotor*, float *sensitivity* = 0.5)

Constructor for [RobotDrive](#) with 2 motors specified as [SpeedController](#) objects. The [SpeedController](#) version of the constructor enables programs to use the [RobotDrive](#) classes with subclasses of the [SpeedController](#) objects, for example, versions with ramping or reshaping of the curve to suit motor bias or deadband elimination.

Parameters:

leftMotor The left [SpeedController](#) object used to drive the robot.

rightMotor the right [SpeedController](#) object used to drive the robot.

sensitivity Effectively sets the turning sensitivity (or turn radius for a given value)

5.35.2.4 RobotDrive::RobotDrive (SpeedController * *frontLeftMotor*, SpeedController * *rearLeftMotor*, SpeedController * *frontRightMotor*, SpeedController * *rearRightMotor*, float *sensitivity* = 0.5)

Constructor for [RobotDrive](#) with 4 motors specified as [SpeedController](#) objects. Speed controller input version of [RobotDrive](#) (see previous comments).

Parameters:

rearLeftMotor The back left [SpeedController](#) object used to drive the robot.

frontLeftMotor The front left [SpeedController](#) object used to drive the robot

rearRightMotor The back right [SpeedController](#) object used to drive the robot.

frontRightMotor The front right [SpeedController](#) object used to drive the robot.

sensitivity Effectively sets the turning sensitivity (or turn radius for a given value)

5.35.2.5 RobotDrive::~~RobotDrive () [virtual]

[RobotDrive](#) destructor. Deletes motor objects that were not passed in and created internally only.

5.35.3 Member Function Documentation

5.35.3.1 void RobotDrive::ArcadeDrive (float *moveValue*, float *rotateValue*, bool *squaredInputs* = true)

Arcade drive implements single stick driving. This function lets you directly provide joystick values from any source.

Parameters:

- moveValue* The value to use for forwards/backwards
- rotateValue* The value to use for the rotate right/left
- squaredInputs* If set, increases the sensitivity at low speeds

5.35.3.2 void RobotDrive::ArcadeDrive (GenericHID & *moveStick*, UINT32 *moveAxis*, GenericHID & *rotateStick*, UINT32 *rotateAxis*, bool *squaredInputs* = true)

Arcade drive implements single stick driving. Given two joystick instances and two axis, compute the values to send to either two or four motors.

Parameters:

- moveStick* The [Joystick](#) object that represents the forward/backward direction
- moveAxis* The axis on the moveStick object to use for forwards/backwards (typically Y_AXIS)
- rotateStick* The [Joystick](#) object that represents the rotation value
- rotateAxis* The axis on the rotation object to use for the rotate right/left (typically X_AXIS)
- squaredInputs* Setting this parameter to true increases the sensitivity at lower speeds

5.35.3.3 void RobotDrive::ArcadeDrive (GenericHID * *moveStick*, UINT32 *moveAxis*, GenericHID * *rotateStick*, UINT32 *rotateAxis*, bool *squaredInputs* = true)

Arcade drive implements single stick driving. Given two joystick instances and two axis, compute the values to send to either two or four motors.

Parameters:

- moveStick* The [Joystick](#) object that represents the forward/backward direction
- moveAxis* The axis on the moveStick object to use for forwards/backwards (typically Y_AXIS)
- rotateStick* The [Joystick](#) object that represents the rotation value
- rotateAxis* The axis on the rotation object to use for the rotate right/left (typically X_AXIS)
- squaredInputs* Setting this parameter to true increases the sensitivity at lower speeds

5.35.3.4 void RobotDrive::ArcadeDrive (GenericHID & *stick*, bool *squaredInputs* = true)

Arcade drive implements single stick driving. Given a single [Joystick](#), the class assumes the Y axis for the move value and the X axis for the rotate value. (Should add more information here regarding the way that arcade drive works.)

Parameters:

stick The joystick to use for Arcade single-stick driving. The Y-axis will be selected for forwards/backwards and the X-axis will be selected for rotation rate.

squaredInputs If true, the sensitivity will be increased for small values

5.35.3.5 void RobotDrive::ArcadeDrive (GenericHID * *stick*, bool *squaredInputs* = true)

Arcade drive implements single stick driving. Given a single [Joystick](#), the class assumes the Y axis for the move value and the X axis for the rotate value. (Should add more information here regarding the way that arcade drive works.)

Parameters:

stick The joystick to use for Arcade single-stick driving. The Y-axis will be selected for forwards/backwards and the X-axis will be selected for rotation rate.

squaredInputs If true, the sensitivity will be increased for small values

5.35.3.6 void RobotDrive::Drive (float *speed*, float *curve*)

Drive the motors at "speed" and "curve".

The speed and curve are -1.0 to +1.0 values where 0.0 represents stopped and not turning. The algorithm for adding in the direction attempts to provide a constant turn radius for differing speeds.

This function will most likely be used in an autonomous routine.

Parameters:

speed The forward component of the speed to send to the motors.

curve The rate of turn, constant for different forward speeds.

5.35.3.7 void RobotDrive::HolonomicDrive (float *magnitude*, float *direction*, float *rotation*)

Holonomic Drive class for Mecanum wheeled robots.

Experimental class for driving with Mecanum wheeled robots. There are 4 wheels on the robot, arranged so that the front and back wheels are toed in 45 degrees.

Parameters:

magnitude The speed that the robot should drive in a given direction.

direction The direction the robot should drive. The direction and magnitude are independent of the rotation rate.

rotation The rate of rotation for the robot that is completely independent of the magnitude or direction.

5.35.3.8 void RobotDrive::SetLeftRightMotorSpeeds (float *leftSpeed*, float *rightSpeed*)

Set the speed of the right and left motors. This is used once an appropriate drive setup function is called such as TwoWheelDrive(). The motors are set to "leftSpeed" and "rightSpeed" and includes flipping the direction of one side for opposing motors.

Parameters:

leftSpeed The speed to send to the left side of the robot.

rightSpeed The speed to send to the right side of the robot.

5.35.3.9 void RobotDrive::TankDrive (float *leftValue*, float *rightValue*)

Provide tank steering using the stored robot configuration. This function lets you directly provide joystick values from any source.

Parameters:

leftValue The value of the left stick.

rightValue The value of the right stick.

5.35.3.10 void RobotDrive::TankDrive (GenericHID * *leftStick*, UINT32 *leftAxis*, GenericHID * *rightStick*, UINT32 *rightAxis*)

Provide tank steering using the stored robot configuration. This function lets you pick the axis to be used on each Joystick object for the left and right sides of the robot.

Parameters:

leftStick The Joystick object to use for the left side of the robot.

leftAxis The axis to select on the left side Joystick object.

rightStick The Joystick object to use for the right side of the robot.

rightAxis The axis to select on the right side Joystick object.

5.35.3.11 void RobotDrive::TankDrive (GenericHID * *leftStick*, GenericHID * *rightStick*)

Provide tank steering using the stored robot configuration. Drive the robot using two joystick inputs. The Y-axis will be selected from each Joystick object.

Parameters:

leftStick The joystick to control the left side of the robot.

rightStick The joystick to control the right side of the robot.

The documentation for this class was generated from the following files:

- RobotDrive.h
- RobotDrive.cpp

5.36 ScopedSocket Class Reference

Implements an object that automatically does a close on a camera socket on destruction.

5.36.1 Detailed Description

Implements an object that automatically does a close on a camera socket on destruction.

The documentation for this class was generated from the following file:

- PCVideoServer.cpp

5.37 SensorBase Class Reference

```
#include <SensorBase.h>
```

Inherits [ErrorBase](#).

Inherited by [Accelerometer](#), [AnalogChannel](#), [AnalogTrigger](#), [Compressor](#), [Counter](#), [DigitalOutput](#)_[private], [DriverStation](#), [Encoder](#), [Gyro](#), [HiTechnicCompass](#), [I2C](#)_[private], [InterruptableSensorBase](#), [Module](#), [PWM](#), [Relay](#), [Solenoid](#), [Ultrasonic](#), and [Watchdog](#).

Public Member Functions

- [SensorBase](#) ()
- virtual [~SensorBase](#) ()

Static Public Member Functions

- static void [SetDefaultAnalogModule](#) (UINT32 slot)
- static void [SetDefaultDigitalModule](#) (UINT32 slot)
- static void [SetDefaultSolenoidModule](#) (UINT32 slot)
- static void [DeleteSingletons](#) ()
- static bool [CheckDigitalModule](#) (UINT32 slot)
- static bool [CheckRelayModule](#) (UINT32 slot)
- static bool [CheckPWMModule](#) (UINT32 slot)
- static bool [CheckSolenoidModule](#) (UINT32 slot)
- static bool [CheckAnalogModule](#) (UINT32 slot)
- static bool [CheckDigitalChannel](#) (UINT32 channel)
- static bool [CheckRelayChannel](#) (UINT32 channel)
- static bool [CheckPWMChannel](#) (UINT32 channel)
- static bool [CheckAnalogChannel](#) (UINT32 channel)
- static bool [CheckSolenoidChannel](#) (UINT32 channel)

Protected Member Functions

- void [AddToSingletonList](#) ()

5.37.1 Detailed Description

Base class for all sensors. Stores most recent status information as well as containing utility functions for checking channels and error processing.

5.37.2 Constructor & Destructor Documentation

5.37.2.1 [SensorBase::SensorBase](#) ()

Creates an instance of the sensor base and gets an FPGA handle

5.37.2.2 SensorBase::~~SensorBase () [virtual]

Frees the resources for a [SensorBase](#).

5.37.3 Member Function Documentation

5.37.3.1 void SensorBase::AddToSingletonList () [protected]

Add sensor to the singleton list. Add this sensor to the list of singletons that need to be deleted when the robot program exits. Each of the sensors on this list are singletons, that is they aren't allocated directly with new, but instead are allocated by the static GetInstance method. As a result, they are never deleted when the program exits. Consequently these sensors may still be holding onto resources and need to have their destructors called at the end of the program.

5.37.3.2 bool SensorBase::CheckAnalogChannel (UINT32 *channel*) [static]

Check that the analog channel number is value. Verify that the analog channel number is one of the legal channel numbers. Channel numbers are 1-based.

5.37.3.3 bool SensorBase::CheckAnalogModule (UINT32 *slot*) [static]

Check that the analog module number is valid. Module numbers are the slot numbers that they are inserted in.

5.37.3.4 bool SensorBase::CheckDigitalChannel (UINT32 *channel*) [static]

Check that the digital channel number is valid. Verify that the channel number is one of the legal channel numbers. Channel numbers are 0-based.

5.37.3.5 bool SensorBase::CheckDigitalModule (UINT32 *slot*) [static]

Check that the digital module number is valid. Module numbers are the slot number that they are inserted in.

5.37.3.6 bool SensorBase::CheckPWMChannel (UINT32 *channel*) [static]

Check that the digital channel number is valid. Verify that the channel number is one of the legal channel numbers. Channel numbers are 0-based.

5.37.3.7 bool SensorBase::CheckPWMModule (UINT32 *slot*) [static]

Check that the digital module number is valid. Module numbers are the slot number that they are inserted in.

5.37.3.8 bool SensorBase::CheckRelayChannel (UINT32 *channel*) [static]

Check that the digital channel number is valid. Verify that the channel number is one of the legal channel numbers. Channel numbers are 0-based.

5.37.3.9 bool SensorBase::CheckRelayModule (UINT32 *slot*) [static]

Check that the digital module number is valid. Module numbers are the slot number that they are inserted in.

5.37.3.10 bool SensorBase::CheckSolenoidChannel (UINT32 *channel*) [static]

Verify that the solenoid channel number is within limits.

5.37.3.11 bool SensorBase::CheckSolenoidModule (UINT32 *slot*) [static]

Verify that the solenoid module is correct. Verify that the solenoid module is slot 8 (for now).

5.37.3.12 void SensorBase::DeleteSingletons () [static]

Delete all the singleton classes on the list. All the classes that were allocated as singletons need to be deleted so their resources can be freed.

5.37.3.13 void SensorBase::SetDefaultAnalogModule (UINT32 *slot*) [static]

Sets the default Analog module. This sets the default analog module to use for objects that are created without specifying the analog module in the constructor. The default module is initialized to the first module in the chassis.

5.37.3.14 void SensorBase::SetDefaultDigitalModule (UINT32 *slot*) [static]

Sets the default Digital Module. This sets the default digital module to use for objects that are created without specifying the digital module in the constructor. The default module is initialized to the first module in the chassis.

5.37.3.15 void SensorBase::SetDefaultSolenoidModule (UINT32 *slot*) [static]

Set the default location for the [Solenoid](#) (9472) module. Currently the module must be in slot 8, but it might change in the future.

The documentation for this class was generated from the following files:

- SensorBase.h
- SensorBase.cpp

5.38 SerialPort Class Reference

```
#include <SerialPort.h>
```

Public Member Functions

- [SerialPort](#) (UINT32 baudRate, UINT8 dataBits=8, Parity parity=kParity_None, StopBits stopBits=kStopBits_One)
- [~SerialPort](#) ()
- void [SetFlowControl](#) (FlowControl flowControl)
- void [EnableTermination](#) (char terminator= '\n')
- void [DisableTermination](#) ()
- INT32 [GetBytesReceived](#) ()
- void [Printf](#) (const char *writeFmt,...)
- void [Scanf](#) (const char *readFmt,...)
- UINT32 [Read](#) (char *buffer, INT32 count)
- UINT32 [Write](#) (const char *buffer, INT32 count)
- void [SetTimeout](#) (float timeout)
- void [SetWriteBufferMode](#) (WriteBufferMode mode)
- void [Flush](#) ()
- void [Reset](#) ()

5.38.1 Detailed Description

Driver for the RS-232 serial port on the cRIO.

The current implementation uses the VISA formatted I/O mode. This means that all traffic goes through the formatted buffers. This allows the intermingled use of [Printf\(\)](#), [Scanf\(\)](#), and the raw buffer accessors [Read\(\)](#) and [Write\(\)](#).

More information can be found in the NI-VISA User Manual here: <http://www.ni.com/pdf/manuals/370423a.pdf> and the NI-VISA Programmer's Reference Manual here: <http://www.ni.com/pdf/manuals/370132c.pdf>

5.38.2 Constructor & Destructor Documentation

5.38.2.1 [SerialPort::SerialPort](#) (UINT32 *baudRate*, UINT8 *dataBits* = 8, [SerialPort::Parity](#) *parity* = kParity_None, [SerialPort::StopBits](#) *stopBits* = kStopBits_One)

Create an instance of a Serial Port class.

Parameters:

baudRate The baud rate to configure the serial port. The cRIO-9074 supports up to 230400 Baud.

dataBits The number of data bits per transfer. Valid values are between 5 and 8 bits.

parity Select the type of parity checking to use.

stopBits The number of stop bits to use as defined by the enum StopBits.

5.38.2.2 SerialPort::~~SerialPort ()

Destructor.

5.38.3 Member Function Documentation

5.38.3.1 void SerialPort::DisableTermination ()

Disable termination behavior.

5.38.3.2 void SerialPort::EnableTermination (char *terminator* = ' \n ')

Enable termination and specify the termination character.

Termination is currently only implemented for receive. When the the terminator is recieved, the [Read\(\)](#) or [Scanf\(\)](#) will return fewer bytes than requested, stopping after the terminator.

Parameters:

terminator The character to use for termination.

5.38.3.3 void SerialPort::Flush ()

Force the output buffer to be written to the port.

This is used when [SetWriteBufferMode\(\)](#) is set to kFlushWhenFull to force a flush before the buffer is full.

5.38.3.4 INT32 SerialPort::GetBytesReceived ()

Get the number of bytes currently available to read from the serial port.

Returns:

The number of bytes available to read.

5.38.3.5 void SerialPort::Printf (const char * *writeFmt*, ...)

Output formatted text to the serial port.

Bug

All pointer-based parameters seem to return an error.

Parameters:

writeFmt A string that defines the format of the output.

5.38.3.6 UINT32 SerialPort::Read (char * *buffer*, INT32 *count*)

Read raw bytes out of the buffer.

Parameters:

buffer Pointer to the buffer to store the bytes in.

count The maximum number of bytes to read.

Returns:

The number of bytes actually read into the buffer.

5.38.3.7 void SerialPort::Reset ()

Reset the serial port driver to a known state.

Empty the transmit and receive buffers in the device and formatted I/O.

5.38.3.8 void SerialPort::Scanf (const char * *readFmt*, ...)

Input formatted text from the serial port.

Bug

All pointer-based parameters seem to return an error.

Parameters:

readFmt A string that defines the format of the input.

5.38.3.9 void SerialPort::SetFlowControl (SerialPort::FlowControl *flowControl*)

Set the type of flow control to enable on this port.

By default, flow control is disabled.

5.38.3.10 void SerialPort::SetTimeout (float *timeout*)

Configure the timeout of the serial port.

This defines the timeout for transactions with the hardware. It will affect reads and very large writes.

Parameters:

timeout The number of seconds to wait for I/O.

5.38.3.11 void SerialPort::SetWriteBufferMode (SerialPort::WriteBufferMode *mode*)

Specify the flushing behavior of the output buffer.

When set to kFlushOnAccess, data is synchronously written to the serial port after each call to either [Printf\(\)](#) or [Write\(\)](#).

When set to kFlushWhenFull, data will only be written to the serial port when the buffer is full or when [Flush\(\)](#) is called.

Parameters:

mode The write buffer mode.

5.38.3.12 UINT32 SerialPort::Write (const char * *buffer*, INT32 *count*)

Write raw bytes to the buffer.

Parameters:

buffer Pointer to the buffer to read the bytes from.

count The maximum number of bytes to write.

Returns:

The number of bytes actually written into the port.

The documentation for this class was generated from the following files:

- SerialPort.h
- SerialPort.cpp

5.39 Servo Class Reference

```
#include <Servo.h>
```

Inherits [PWM](#), and [SpeedController](#).

Public Member Functions

- [Servo](#) (UINT32 channel)
- [Servo](#) (UINT32 slot, UINT32 channel)
- void [Set](#) (float value)
- float [Get](#) ()
- void [SetAngle](#) (float angle)
- float [GetAngle](#) ()

5.39.1 Detailed Description

Standard hobby style servo.

The range parameters default to the appropriate values for the Hitec HS-322HD servo provided in the FIRST Kit of Parts in 2008.

5.39.2 Constructor & Destructor Documentation

5.39.2.1 [Servo::Servo \(UINT32 *channel*\)](#) `[explicit]`

Constructor that assumes the default digital module.

Parameters:

channel The [PWM](#) channel on the digital module to which the servo is attached.

5.39.2.2 [Servo::Servo \(UINT32 *slot*, UINT32 *channel*\)](#)

Constructor that specifies the digital module.

Parameters:

slot The slot in the chassis that the digital module is plugged into.

channel The [PWM](#) channel on the digital module to which the servo is attached.

5.39.3 Member Function Documentation

5.39.3.1 [float Servo::Get \(\)](#) `[virtual]`

Get the servo position.

[Servo](#) values range from 0.0 to 1.0 corresponding to the range of full left to full right.

Returns:

Position from 0.0 to 1.0.

Implements [SpeedController](#).

5.39.3.2 float Servo::GetAngle ()

Get the servo angle.

Assume that the servo angle is linear with respect to the [PWM](#) value (big assumption, need to test).

Returns:

The angle in degrees to which the servo is set.

5.39.3.3 void Servo::Set (float *value*) [virtual]

Set the servo position.

[Servo](#) values range from 0.0 to 1.0 corresponding to the range of full left to full right.

Parameters:

value Position from 0.0 to 1.0.

Implements [SpeedController](#).

5.39.3.4 void Servo::SetAngle (float *degrees*)

Set the servo angle.

Assume that the servo angle is linear with respect to the [PWM](#) value (big assumption, need to test).

[Servo](#) angles that are out of the supported range of the servo simply "saturate" in that direction. In other words, if the servo has a range of (X degrees to Y degrees) then angles of less than X result in an angle of X being set and angles of more than Y degrees result in an angle of Y being set.

Parameters:

degrees The angle in degrees to set the servo.

The documentation for this class was generated from the following files:

- Servo.h
- Servo.cpp

5.40 SimpleRobot Class Reference

```
#include <SimpleRobot.h>
```

Inherits [RobotBase](#).

Public Member Functions

- virtual void [Autonomous](#) ()
- virtual void [OperatorControl](#) ()
- virtual void [RobotMain](#) ()
- void [StartCompetition](#) ()

5.40.1 Detailed Description

[Todo](#)

If this is going to last until release, it needs a better name.

5.40.2 Member Function Documentation

5.40.2.1 void SimpleRobot::Autonomous () [virtual]

Autonomous should go here. Users should add autonomous code to this method that should run while the field is in the autonomous period.

5.40.2.2 void SimpleRobot::OperatorControl () [virtual]

Operator control (tele-operated) code should go here. Users should add Operator Control code to this method that should run while the field is in the Operator Control (tele-operated) period.

5.40.2.3 void SimpleRobot::RobotMain () [virtual]

Robot main program for free-form programs.

This should be overridden by user subclasses if the intent is to not use the [Autonomous\(\)](#) and [OperatorControl\(\)](#) methods. In that case, the program is responsible for sensing when to run the autonomous and operator control functions in their program.

This method will be called immediately after the constructor is called. If it has not been overridden by a user subclass (i.e. the default version runs), then the [Autonomous\(\)](#) and [OperatorControl\(\)](#) methods will be called.

5.40.2.4 void SimpleRobot::StartCompetition () [virtual]

Start a competition. This code needs to track the order of the field starting to ensure that everything happens in the right order. Repeatedly run the correct method, either Autonomous or OperatorControl when the robot is enabled. After running the correct method, wait for some state to change, either the other mode starts or the robot is disabled. Then go back and wait for the robot to be enabled again.

Implements [RobotBase](#).

The documentation for this class was generated from the following files:

- SimpleRobot.h
- SimpleRobot.cpp

5.41 Solenoid Class Reference

```
#include <Solenoid.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [Solenoid](#) (UINT32 channel)
- [Solenoid](#) (UINT32 slot, UINT32 channel)
- [~Solenoid](#) ()
- void [Set](#) (bool on)
- bool [Get](#) ()

Protected Member Functions

- UINT32 [SlotToIndex](#) (UINT32 slot)

5.41.1 Detailed Description

[Solenoid](#) class for running high voltage Digital Output (9472 module).

The [Solenoid](#) class is typically used for pneumatics solenoids, but could be used for any device within the current spec of the 9472 module.

5.41.2 Constructor & Destructor Documentation

5.41.2.1 Solenoid::Solenoid (UINT32 *channel*) [explicit]

Constructor.

Parameters:

channel The channel on the module to control.

5.41.2.2 Solenoid::Solenoid (UINT32 *slot*, UINT32 *channel*)

Constructor.

Parameters:

slot The slot that the 9472 module is plugged into.

channel The channel on the module to control.

5.41.2.3 Solenoid::~Solenoid ()

Destructor.

5.41.3 Member Function Documentation

5.41.3.1 `bool Solenoid::Get ()`

Read the current value of the solenoid.

Returns:

The current value of the solenoid.

5.41.3.2 `void Solenoid::Set (bool on)`

Set the value of a solenoid.

Parameters:

on Turn the solenoid output off or on.

5.41.3.3 `UINT32 Solenoid::SlotToIndex (UINT32 slot)` [protected]

Convert slot number to index.

Parameters:

slot The slot in the chassis where the module is plugged in.

Returns:

An index to represent the module internally.

The documentation for this class was generated from the following files:

- Solenoid.h
- Solenoid.cpp

5.42 SpeedController Class Reference

```
#include <SpeedController.h>
```

Inherited by [Jaguar](#), [Servo](#), and [Victor](#).

Public Member Functions

- virtual void [Set](#) (float speed)=0
- virtual float [Get](#) ()=0

5.42.1 Detailed Description

Interface for speed controlling devices.

5.42.2 Member Function Documentation

5.42.2.1 virtual float SpeedController::Get () [pure virtual]

Common interface for getting the current set speed of a speed controller.

Returns:

The current set speed. Value is between -1.0 and 1.0.

Implemented in [Jaguar](#), [Servo](#), and [Victor](#).

5.42.2.2 virtual void SpeedController::Set (float *speed*) [pure virtual]

Common interface for setting the speed of a speed controller.

Parameters:

speed The speed to set. Value should be between -1.0 and 1.0.

Implemented in [Jaguar](#), [Servo](#), and [Victor](#).

The documentation for this class was generated from the following file:

- SpeedController.h

5.43 Synchronized Class Reference

```
#include <Synchronized.h>
```

Public Member Functions

- [Synchronized](#) (SEM_ID)
- virtual [~Synchronized](#) ()

5.43.1 Detailed Description

Provide easy support for critical regions. A critical region is an area of code that is always executed under mutual exclusion. Only one task can be executing this code at any time. The idea is that code that manipulates data that is shared between two or more tasks has to be prevented from executing at the same time otherwise a race condition is possible when both tasks try to update the data. Typically semaphores are used to ensure only single task access to the data. [Synchronized](#) objects are a simple wrapper around semaphores to help ensure that semaphores are always signaled (semGive) after a wait (semTake).

5.43.2 Constructor & Destructor Documentation

5.43.2.1 [Synchronized::Synchronized \(SEM_ID semaphore\)](#) [explicit]

[Synchronized](#) class deals with critical regions. Declare a [Synchronized](#) object at the beginning of a block. That will take the semaphore. When the code exits from the block it will call the destructor which will give the semaphore. This ensures that no matter how the block is exited, the semaphore will always be released. Use the CRITICAL_REGION(SEM_ID) and END_REGION macros to make the code look cleaner (see header file)

Parameters:

semaphore The semaphore controlling this critical region.

5.43.2.2 [Synchronized::~~Synchronized \(\)](#) [virtual]

Synchronized destructor. This destructor frees the semaphore ensuring that the resource is freed for the block containing the [Synchronized](#) object.

The documentation for this class was generated from the following files:

- Synchronized.h
- Synchronized.cpp

5.44 Task Class Reference

```
#include <Task.h>
```

Public Member Functions

- **Task** (char *name, FUNCPTR function, INT32 priority=kDefaultPriority, UINT32 stackSize=20000)
- bool **Start** (UINT32 arg0=0, UINT32 arg1=0, UINT32 arg2=0, UINT32 arg3=0, UINT32 arg4=0, UINT32 arg5=0, UINT32 arg6=0, UINT32 arg7=0, UINT32 arg8=0, UINT32 arg9=0)
- bool **Restart** (void)
- bool **Stop** (void)
- bool **IsReady** (void)
- bool **IsSuspended** (void)
- bool **Suspend** (void)
- bool **Resume** (void)
- bool **Verify** (void)
- INT32 **GetPriority** (void)
- bool **SetPriority** (INT32 priority)
- char * **GetName** (void)
- INT32 **GetID** (void)

5.44.1 Detailed Description

WPI task is a wrapper for the native **Task** object. All WPILib tasks are managed by a static task manager for simplified cleanup.

5.44.2 Constructor & Destructor Documentation

5.44.2.1 Task::Task (char * name, FUNCPTR function, INT32 priority = kDefaultPriority, UINT32 stackSize = 20000)

Create but don't launch a task.

Parameters:

- name** The name of the task. "FRC" will be prepended to the task name.
- function** The address of the function to run as the new task.
- priority** The VxWorks priority for the task.
- stackSize** The size of the stack for the task

5.44.3 Member Function Documentation

5.44.3.1 INT32 Task::GetID (void)

Get the ID of a task

Returns:

- task ID of this task.

5.44.3.2 char * Task::GetName (void)

Returns the name of the task.

Returns:

Pointer to the name of the task or NULL if not allocated

5.44.3.3 INT32 Task::GetPriority (void)

Gets the priority of a task.

Returns:

task priority or 0 if an error occurred

5.44.3.4 bool Task::IsReady (void)

Returns true if the task is ready to execute (i.e. not suspended, delayed, or blocked).

Returns:

true if ready, false if not ready.

5.44.3.5 bool Task::IsSuspended (void)

Returns true if the task was explicitly suspended by calling [Suspend\(\)](#)

Returns:

true if suspended, false if not suspended.

5.44.3.6 bool Task::Restart (void)

Restarts a running task. If the task isn't started, it starts it.

Returns:

false if the task is running and we are unable to kill the previous instance

5.44.3.7 bool Task::Resume (void)

Resumes a paused task. Returns true on success, false if unable to resume or if the task isn't running/paused.

5.44.3.8 bool Task::SetPriority (INT32 *priority*)

This routine changes a task's priority to a specified priority. Priorities range from 0, the highest priority, to 255, the lowest priority. Default task priority is 100.

Parameters:

priority The priority the task should run at.

Returns:

true on success.

5.44.3.9 `bool Task::Start (UINT32 arg0 = 0, UINT32 arg1 = 0, UINT32 arg2 = 0, UINT32 arg3 = 0, UINT32 arg4 = 0, UINT32 arg5 = 0, UINT32 arg6 = 0, UINT32 arg7 = 0, UINT32 arg8 = 0, UINT32 arg9 = 0)`

Starts this task. If it is already running or unable to start, it fails and returns false.

5.44.3.10 `bool Task::Stop (void)`

Kills the running task.

Returns:

true on success false if the task doesn't exist or we are unable to kill it.

5.44.3.11 `bool Task::Suspend (void)`

Pauses a running task. Returns true on success, false if unable to pause or the task isn't running.

5.44.3.12 `bool Task::Verify (void)`

Verifies a task still exists.

Returns:

true on success.

The documentation for this class was generated from the following files:

- Task.h
- Task.cpp

5.45 Timer Class Reference

```
#include <Timer.h>
```

Public Member Functions

- [Timer](#) ()
- double [Get](#) ()
- void [Reset](#) ()
- void [Start](#) ()
- void [Stop](#) ()

5.45.1 Detailed Description

[Timer](#) objects measure accumulated time in seconds. The timer object functions like a stopwatch. It can be started, stopped, and cleared. When the timer is running its value counts up in seconds. When stopped, the timer holds the current value. The implementation simply records the time when started and subtracts the current time whenever the value is requested.

5.45.2 Constructor & Destructor Documentation

5.45.2.1 [Timer::Timer](#) ()

Create a new timer object.

Create a new timer object and reset the time to zero. The timer is initially not running and must be started.

5.45.3 Member Function Documentation

5.45.3.1 [double Timer::Get](#) ()

Get the current time from the timer. If the clock is running it is derived from the current system clock the start time stored in the timer class. If the clock is not running, then return the time when it was last stopped.

Returns:

unsigned Current time value for this timer in seconds

5.45.3.2 [void Timer::Reset](#) ()

Reset the timer by setting the time to 0.

Make the timer start time the current time so new requests will be relative now

5.45.3.3 [void Timer::Start](#) ()

Start the timer running. Just set the running flag to true indicating that all time requests should be relative to the system clock.

5.45.3.4 void Timer::Stop ()

Stop the timer. This computes the time as of now and clears the running flag, causing all subsequent time requests to be read from the accumulated time rather than looking at the system clock.

The documentation for this class was generated from the following files:

- Timer.h
- Timer.cpp

5.46 Ultrasonic Class Reference

```
#include <Ultrasonic.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [Ultrasonic](#) ([DigitalOutput](#) *pingChannel, [DigitalInput](#) *echoChannel)
- [Ultrasonic](#) ([DigitalOutput](#) &pingChannel, [DigitalInput](#) &echoChannel)
- [Ultrasonic](#) (UINT32 pingChannel, UINT32 echoChannel)
- [Ultrasonic](#) (UINT32 pingSlot, UINT32 pingChannel, UINT32 echoSlot, UINT32 echoChannel)
- virtual [~Ultrasonic](#) ()
- void [Ping](#) ()
- bool [IsRangeValid](#) ()
- double [GetRangeInches](#) ()
- double [GetRangeMM](#) ()

Static Public Member Functions

- static void [SetAutomaticMode](#) (bool enabling)

5.46.1 Detailed Description

[Ultrasonic](#) rangefinder class. The [Ultrasonic](#) rangefinder measures absolute distance based on the round-trip time of a ping generated by the controller. These sensors use two transducers, a speaker and a microphone both tuned to the ultrasonic range. A common ultrasonic sensor, the Daventech SRF04 requires a short pulse to be generated on a digital channel. This causes the chirp to be emitted. A second line becomes high as the ping is transmitted and goes low when the echo is received. The time that the line is high determines the round trip distance (time of flight).

5.46.2 Constructor & Destructor Documentation

5.46.2.1 [Ultrasonic::Ultrasonic](#) ([DigitalOutput](#) * *pingChannel*, [DigitalInput](#) * *echoChannel*)

Create an instance of an [Ultrasonic](#) Sensor from a [DigitalInput](#) for the echo channel and a [DigitalOutput](#) for the ping channel.

Parameters:

pingChannel The digital output object that starts the sensor doing a ping. Requires a 10uS pulse to start.

echoChannel The digital input object that times the return pulse to determine the range.

5.46.2.2 [Ultrasonic::Ultrasonic](#) ([DigitalOutput](#) & *pingChannel*, [DigitalInput](#) & *echoChannel*)

Create an instance of an [Ultrasonic](#) Sensor from a [DigitalInput](#) for the echo channel and a [DigitalOutput](#) for the ping channel.

Parameters:

pingChannel The digital output object that starts the sensor doing a ping. Requires a 10uS pulse to start.

echoChannel The digital input object that times the return pulse to determine the range.

5.46.2.3 Ultrasonic::Ultrasonic (UINT32 pingChannel, UINT32 echoChannel)

Create an instance of the [Ultrasonic](#) Sensor using the default module. This is designed to supchannel the Daventech SRF04 and Vex ultrasonic sensors. This constructor assumes that both digital I/O channels are in the default digital module.

Parameters:

pingChannel The digital output channel that sends the pulse to initiate the sensor sending the ping.

echoChannel The digital input channel that receives the echo. The length of time that the echo is high represents the round trip time of the ping, and the distance.

5.46.2.4 Ultrasonic::Ultrasonic (UINT32 pingSlot, UINT32 pingChannel, UINT32 echoSlot, UINT32 echoChannel)

Create an instance of the [Ultrasonic](#) sensor using specified modules. This is designed to supchannel the Daventech SRF04 and Vex ultrasonic sensors. This constructors takes the channel and module slot for each of the required digital I/O channels.

Parameters:

pingSlot The digital module that the pingChannel is in.

pingChannel The digital output channel that sends the pulse to initiate the sensor sending the ping.

echoSlot The digital module that the echoChannel is in.

echoChannel The digital input channel that receives the echo. The length of time that the echo is high represents the round trip time of the ping, and the distance.

5.46.2.5 Ultrasonic::~Ultrasonic () [virtual]

Destructor for the ultrasonic sensor. Delete the instance of the ultrasonic sensor by freeing the allocated digital channels. If the system was in automatic mode (round robin), then it is stopped, then started again after this sensor is removed (provided this wasn't the last sensor).

5.46.3 Member Function Documentation**5.46.3.1 double Ultrasonic::GetRangeInches ()**

Get the range in inches from the ultrasonic sensor.

Returns:

double Range in inches of the target returned from the ultrasonic sensor. If there is no valid value yet, i.e. at least one measurement hasn't completed, then return 0.

5.46.3.2 double Ultrasonic::GetRangeMM ()

Get the range in millimeters from the ultrasonic sensor.

Returns:

double Range in millimeters of the target returned by the ultrasonic sensor. If there is no valid value yet, i.e. at least one measurement hasn't completed, then return 0.

5.46.3.3 bool Ultrasonic::IsRangeValid ()

Check if there is a valid range measurement. The ranges are accumulated in a counter that will increment on each edge of the echo (return) signal. If the count is not at least 2, then the range has not yet been measured, and is invalid.

5.46.3.4 void Ultrasonic::Ping ()

Single ping to ultrasonic sensor. Send out a single ping to the ultrasonic sensor. This only works if automatic (round robin) mode is disabled. A single ping is sent out, and the counter should count the semi-period when it comes in. The counter is reset to make the current value invalid.

5.46.3.5 void Ultrasonic::SetAutomaticMode (bool *enabling*) [static]

Turn Automatic mode on/off. When in Automatic mode, all sensors will fire in round robin, waiting a set time between each sensor.

Parameters:

enabling Set to true if round robin scheduling should start for all the ultrasonic sensors. This scheduling method assures that the sensors are non-interfering because no two sensors fire at the same time. If another scheduling algorithm is preferred, it can be implemented by pinging the sensors manually and waiting for the results to come back.

The documentation for this class was generated from the following files:

- Ultrasonic.h
- Ultrasonic.cpp

5.47 Victor Class Reference

```
#include <Victor.h>
```

Inherits [PWM](#), and [SpeedController](#).

Public Member Functions

- [Victor](#) (UINT32 channel)
- [Victor](#) (UINT32 slot, UINT32 channel)
- void [Set](#) (float value)
- float [Get](#) ()

5.47.1 Detailed Description

IFI [Victor](#) Speed Controller

5.47.2 Constructor & Destructor Documentation

5.47.2.1 [Victor::Victor \(UINT32 *channel*\)](#) [explicit]

Constructor that assumes the default digital module.

Parameters:

channel The [PWM](#) channel on the digital module that the [Victor](#) is attached to.

5.47.2.2 [Victor::Victor \(UINT32 *slot*, UINT32 *channel*\)](#)

Constructor that specifies the digital module.

Parameters:

slot The slot in the chassis that the digital module is plugged into.

channel The [PWM](#) channel on the digital module that the [Victor](#) is attached to.

5.47.3 Member Function Documentation

5.47.3.1 [float Victor::Get \(\)](#) [virtual]

Get the recently set value of the [PWM](#).

Returns:

The most recently set value for the [PWM](#) between -1.0 and 1.0.

Implements [SpeedController](#).

5.47.3.2 void Victor::Set (float *speed*) [virtual]

Set the [PWM](#) value.

The [PWM](#) value is set using a range of -1.0 to 1.0, appropriately scaling the value for the FPGA.

Parameters:

speed The speed value between -1.0 and 1.0 to set.

Implements [SpeedController](#).

The documentation for this class was generated from the following files:

- Victor.h
- Victor.cpp

5.48 Watchdog Class Reference

```
#include <Watchdog.h>
```

Inherits [SensorBase](#).

Public Member Functions

- [Watchdog](#) ()
- virtual [~Watchdog](#) ()
- bool [Feed](#) ()
- void [Kill](#) ()
- float [GetTimer](#) ()
- float [GetExpiration](#) ()
- void [SetExpiration](#) (float expiration_ms)
- bool [GetEnabled](#) ()
- void [SetEnabled](#) (bool enabled)
- bool [IsAlive](#) ()
- bool [IsSystemActive](#) ()

5.48.1 Detailed Description

[Watchdog](#) timer class. The watchdog timer is designed to keep the robots safe. The idea is that the robot program must constantly "feed" the watchdog otherwise it will shut down all the motor outputs. That way if a program breaks, rather than having the robot continue to operate at the last known speed, the motors will be shut down.

This is serious business. Don't just disable the watchdog. You can't afford it!

http://thedailywtf.com/Articles/_0x2f__0x2f_TODO_0x3a__Uncomment_Later.aspx

5.48.2 Constructor & Destructor Documentation

5.48.2.1 [Watchdog::Watchdog](#) ()

The [Watchdog](#) is born.

5.48.2.2 [Watchdog::~~Watchdog](#) () [virtual]

Time to bury him in the back yard.

5.48.3 Member Function Documentation

5.48.3.1 bool [Watchdog::Feed](#) ()

Throw the dog a bone.

When everything is going well, you feed your dog when you get home. Let's hope you don't drive your car off a bridge on the way home... Your dog won't get fed and he will starve to death.

By the way, it's not cool to ask the neighbor (some random task) to feed your dog for you. He's your responsibility!

Returns:

Returns the previous state of the watchdog before feeding it.

5.48.3.2 bool Watchdog::GetEnabled ()

Find out if the watchdog is currently enabled or disabled (mortal or immortal).

Returns:

Enabled or disabled.

5.48.3.3 float Watchdog::GetExpiration ()

Read what the current expiration is.

Returns:

The number of seconds before starvation following a meal (watchdog starves if it doesn't eat this often).

5.48.3.4 float Watchdog::GetTimer ()

Read how long it has been since the watchdog was last fed.

Returns:

The number of seconds since last meal.

5.48.3.5 bool Watchdog::IsAlive ()

Check in on the watchdog and make sure he's still kicking.

This indicates that your watchdog is allowing the system to operate. It is still possible that the network communications is not allowing the system to run, but you can check this to make sure it's not your fault. Check [IsSystemActive\(\)](#) for overall system status.

If the watchdog is disabled, then your watchdog is immortal.

Returns:

Is the watchdog still alive?

5.48.3.6 bool Watchdog::IsSystemActive ()

Check on the overall status of the system.

Returns:

Is the system active (i.e. [PWM](#) motor outputs, etc. enabled)?

5.48.3.7 void Watchdog::Kill ()

Put the watchdog out of its misery.

Don't wait for your dying robot to starve when there is a problem. Kill it quickly, cleanly, and humanely.

5.48.3.8 void Watchdog::SetEnabled (bool *enabled*)

Enable or disable the watchdog timer.

When enabled, you must keep feeding the watchdog timer to keep the watchdog active, and hence the dangerous parts (motor outputs, etc.) can keep functioning. When disabled, the watchdog is immortal and will remain active even without being fed. It will also ignore any kill commands while disabled.

Parameters:

enabled Enable or disable the watchdog.

5.48.3.9 void Watchdog::SetExpiration (float *expiration*)

Configure how many seconds your watchdog can be neglected before it starves to death.

Parameters:

expiration The number of seconds before starvation following a meal (watchdog starves if it doesn't eat this often).

The documentation for this class was generated from the following files:

- Watchdog.h
- Watchdog.cpp

Index

- ~Accelerometer
 - Accelerometer, [10](#)
- ~AnalogChannel
 - AnalogChannel, [12](#)
- ~AnalogModule
 - AnalogModule, [18](#)
- ~Compressor
 - Compressor, [27](#)
- ~Counter
 - Counter, [30](#)
- ~DigitalInput
 - DigitalInput, [40](#)
- ~DigitalOutput
 - DigitalOutput, [43](#)
- ~DigitalSource
 - DigitalSource, [45](#)
- ~Encoder
 - Encoder, [50](#)
- ~GearTooth
 - GearTooth, [57](#)
- ~Gyro
 - Gyro, [60](#)
- ~HiTechnicCompass
 - HiTechnicCompass, [61](#)
- ~I2C
 - I2C, [63](#)
- ~IterativeRobot
 - IterativeRobot, [66](#)
- ~PIDController
 - PIDController, [78](#)
- ~PWM
 - PWM, [84](#)
- ~Relay
 - Relay, [88](#)
- ~Resource
 - Resource, [90](#)
- ~RobotBase
 - RobotBase, [92](#)
- ~RobotDrive
 - RobotDrive, [97](#)
- ~SensorBase
 - SensorBase, [102](#)
- ~SerialPort
 - SerialPort, [105](#)
- ~Solenoid
 - Solenoid, [113](#)
- ~Synchronized
 - Synchronized, [116](#)
- ~Ultrasonic
 - Ultrasonic, [123](#)
- ~Watchdog
 - Watchdog, [127](#)
- Accelerometer, [9](#)
 - ~Accelerometer, [10](#)
 - Accelerometer, [9, 10](#)
 - GetAcceleration, [10](#)
 - SetSensitivity, [10](#)
 - SetZero, [10](#)
- AddArray
 - Dashboard, [36](#)
- AddBoolean
 - Dashboard, [36](#)
- AddCluster
 - Dashboard, [37](#)
- AddDouble
 - Dashboard, [37](#)
- AddFloat
 - Dashboard, [37](#)
- AddI16
 - Dashboard, [37](#)
- AddI32
 - Dashboard, [37](#)
- AddI8
 - Dashboard, [37](#)
- AddString
 - Dashboard, [38](#)
- AddToSingletonList
 - SensorBase, [103](#)
- AddU16
 - Dashboard, [38](#)
- AddU32
 - Dashboard, [38](#)
- AddU8
 - Dashboard, [38](#)
- Allocate
 - Resource, [90](#)
- AnalogChannel, [11](#)
 - ~AnalogChannel, [12](#)
 - AnalogChannel, [12](#)

- GetAccumulatorCount, [12](#)
- GetAccumulatorOutput, [12](#)
- GetAccumulatorValue, [12](#)
- GetAverageBits, [13](#)
- GetAverageValue, [13](#)
- GetAverageVoltage, [13](#)
- GetChannel, [13](#)
- GetLSBWeight, [13](#)
- GetModule, [14](#)
- GetOffset, [14](#)
- GetOversampleBits, [14](#)
- GetSlot, [14](#)
- GetValue, [14](#)
- GetVoltage, [15](#)
- InitAccumulator, [15](#)
- IsAccumulatorChannel, [15](#)
- ResetAccumulator, [15](#)
- SetAccumulatorCenter, [15](#)
- SetAccumulatorDeadband, [15](#)
- SetAccumulatorInitialValue, [15](#)
- SetAverageBits, [16](#)
- SetOversampleBits, [16](#)
- AnalogModule, [17](#)
- ~AnalogModule, [18](#)
- AnalogModule, [18](#)
- GetAverageBits, [18](#)
- GetAverageValue, [18](#)
- GetAverageVoltage, [18](#)
- GetInstance, [19](#)
- GetLSBWeight, [19](#)
- GetOffset, [19](#)
- GetOversampleBits, [20](#)
- GetSampleRate, [20](#)
- GetValue, [20](#)
- GetVoltage, [20](#)
- SetAverageBits, [20](#)
- SetOversampleBits, [21](#)
- SetSampleRate, [21](#)
- SlotToIndex, [21](#)
- VoltsToValue, [21](#)
- AnalogTriggerOutput, [23](#)
- AnalogTriggerOutput, [23](#)
- Get, [24](#)
- GetAnalogTriggerForRouting, [24](#)
- GetChannelForRouting, [24](#)
- GetModuleForRouting, [24](#)
- RequestInterrupts, [24](#)
- ArcadeDrive
 - RobotDrive, [98, 99](#)
- Autonomous
 - SimpleRobot, [111](#)
- AutonomousContinuous
 - IterativeRobot, [66](#)
- AutonomousInit
 - IterativeRobot, [66](#)
- AutonomousPeriodic
 - IterativeRobot, [66](#)
- Broadcast
 - I2C, [63](#)
- CheckAnalogChannel
 - SensorBase, [103](#)
- CheckAnalogModule
 - SensorBase, [103](#)
- CheckDigitalChannel
 - SensorBase, [103](#)
- CheckDigitalModule
 - SensorBase, [103](#)
- CheckPWMChannel
 - SensorBase, [103](#)
- CheckPWMModule
 - SensorBase, [103](#)
- CheckRelayChannel
 - SensorBase, [103](#)
- CheckRelayModule
 - SensorBase, [103](#)
- CheckSolenoidChannel
 - SensorBase, [104](#)
- CheckSolenoidModule
 - SensorBase, [104](#)
- ClearDownSource
 - Counter, [30](#)
- ClearUpSource
 - Counter, [30](#)
- ColorReport_struct, [26](#)
- Compressor, [27](#)
- ~Compressor, [27](#)
- Compressor, [27](#)
- Enabled, [28](#)
- GetPressureSwitchValue, [28](#)
- SetRelayValue, [28](#)
- Start, [28](#)
- Stop, [28](#)
- Counter, [29](#)
- ~Counter, [30](#)
- ClearDownSource, [30](#)
- ClearUpSource, [30](#)
- Counter, [30](#)
- Get, [30](#)
- GetDirection, [31](#)
- GetStopped, [31](#)
- Reset, [31](#)
- SetDownSource, [31, 32](#)
- SetDownSourceEdge, [32](#)
- SetExternalDirectionMode, [32](#)
- SetMaxPeriod, [32](#)
- SetPulseLengthMode, [32](#)

- SetSemiPeriodMode, 32
- SetUpUpdateWhenEmpty, 33
- SetUpDownCounterMode, 33
- SetUpSource, 33, 34
- SetUpSourceEdge, 34
- Start, 34
- Stop, 34
- CounterBase, 35
- Dashboard, 36
 - AddArray, 36
 - AddBoolean, 36
 - AddCluster, 37
 - AddDouble, 37
 - AddFloat, 37
 - AddI16, 37
 - AddI32, 37
 - AddI8, 37
 - AddString, 38
 - AddU16, 38
 - AddU32, 38
 - AddU8, 38
 - Finalize, 38
 - FinalizeArray, 39
 - FinalizeCluster, 39
 - Printf, 39
- DeleteSingletons
 - SensorBase, 104
- DigitalInput, 40
 - ~DigitalInput, 40
 - DigitalInput, 40
 - GetAnalogTriggerForRouting, 41
 - GetChannel, 41
 - GetChannelForRouting, 41
 - GetModuleForRouting, 41
 - RequestInterrupts, 41
- DigitalOutput, 43
 - ~DigitalOutput, 43
 - DigitalOutput, 43
 - IsPulsing, 43
 - Pulse, 43
 - Set, 43
- DigitalSource, 45
 - ~DigitalSource, 45
- Disable
 - PIDController, 79
- DisabledContinuous
 - IterativeRobot, 66
- DisabledInit
 - IterativeRobot, 66
- DisabledPeriodic
 - IterativeRobot, 67
- DisableTermination
 - SerialPort, 106
- Drive
 - RobotDrive, 99
- DriverStation, 46
 - DriverStation, 46
 - GetAnalogIn, 46
 - GetBatteryVoltage, 47
 - GetData, 47
 - GetDigitalIn, 47
 - GetDigitalOut, 47
 - GetInstance, 47
 - GetPacketNumber, 47
 - GetStickAxis, 47
 - GetStickButtons, 48
 - SetData, 48
 - SetDigitalOut, 48
- Enable
 - PIDController, 79
- Enabled
 - Compressor, 28
- EnableDeadbandElimination
 - PWM, 84
- EnableDirectionSensing
 - GearTooth, 57
- EnableTermination
 - SerialPort, 106
- Encoder, 49
 - ~Encoder, 50
 - Encoder, 49, 50
 - Get, 50
 - GetDirection, 50
 - GetDistance, 51
 - GetPeriod, 51
 - GetStopped, 51
 - Reset, 51
 - SetDistancePerTick, 51
 - SetMaxPeriod, 51
 - SetReverseDirection, 52
 - Start, 52
 - Stop, 52
- Error, 53
- ErrorBase, 54
 - GetGlobalError, 54
 - SetError, 54
 - StatusIsFatal, 55
- Feed
 - Watchdog, 127
- Finalize
 - Dashboard, 38
- FinalizeArray
 - Dashboard, 39
- FinalizeCluster
 - Dashboard, 39

- Flush
 - SerialPort, 106
- Free
 - Resource, 91
- GearTooth, 56
 - ~GearTooth, 57
 - EnableDirectionSensing, 57
 - GearTooth, 56
- GenericHID, 58
- Get
 - AnalogTriggerOutput, 24
 - Counter, 30
 - Encoder, 50
 - Jaguar, 69
 - PIDController, 79
 - Servo, 109
 - Solenoid, 114
 - SpeedController, 115
 - Timer, 120
 - Victor, 125
- GetAcceleration
 - Accelerometer, 10
- GetAccumulatorCount
 - AnalogChannel, 12
- GetAccumulatorOutput
 - AnalogChannel, 12
- GetAccumulatorValue
 - AnalogChannel, 12
- GetAnalogIn
 - DriverStation, 46
- GetAnalogTriggerForRouting
 - AnalogTriggerOutput, 24
 - DigitalInput, 41
- GetAngle
 - Gyro, 60
 - HiTechnicCompass, 61
 - Servo, 110
- GetAverageBits
 - AnalogChannel, 13
 - AnalogModule, 18
- GetAverageValue
 - AnalogChannel, 13
 - AnalogModule, 18
- GetAverageVoltage
 - AnalogChannel, 13
 - AnalogModule, 18
- GetAxis
 - Joystick, 72
- GetAxisChannel
 - Joystick, 72
- GetBatteryVoltage
 - DriverStation, 47
- GetBumper
 - Joystick, 72
- GetButton
 - Joystick, 72
- GetBytesReceived
 - SerialPort, 106
- GetChannel
 - AnalogChannel, 13
 - DigitalInput, 41
- GetChannelForRouting
 - AnalogTriggerOutput, 24
 - DigitalInput, 41
- GetData
 - DriverStation, 47
- GetDigitalIn
 - DriverStation, 47
- GetDigitalOut
 - DriverStation, 47
- GetDirection
 - Counter, 31
 - Encoder, 50
- GetDistance
 - Encoder, 51
- GetEnabled
 - Watchdog, 128
- GetError
 - PIDController, 79
- GetExpiration
 - Watchdog, 128
- GetGlobalError
 - ErrorBase, 54
- GetID
 - Task, 117
- GetInstance
 - AnalogModule, 19
 - DriverStation, 47
- GetLoopsPerSec
 - IterativeRobot, 67
- GetLSBWeight
 - AnalogChannel, 13
 - AnalogModule, 19
- GetModule
 - AnalogChannel, 14
- GetModuleForRouting
 - AnalogTriggerOutput, 24
 - DigitalInput, 41
- GetName
 - Task, 117
- GetOffset
 - AnalogChannel, 14
 - AnalogModule, 19
- GetOversampleBits
 - AnalogChannel, 14
 - AnalogModule, 20
- GetPacketNumber

- DriverStation, 47
- GetPeriod
 - Encoder, 51
- GetPosition
 - PWM, 84
- GetPressureSwitchValue
 - Compressor, 28
- GetPriority
 - Task, 118
- GetRangeInches
 - Ultrasonic, 123
- GetRangeMM
 - Ultrasonic, 123
- GetRaw
 - PWM, 84
- GetRawAxis
 - Joystick, 72
- GetRawButton
 - Joystick, 73
- GetSampleRate
 - AnalogModule, 20
- GetSetpoint
 - PIDController, 79
- GetSlot
 - AnalogChannel, 14
- GetSpeed
 - PWM, 85
- GetStickAxis
 - DriverStation, 47
- GetStickButtons
 - DriverStation, 48
- GetStopped
 - Counter, 31
 - Encoder, 51
- GetThrottle
 - Joystick, 73
- GetTimer
 - Watchdog, 128
- GetTop
 - Joystick, 73
- GetTrigger
 - Joystick, 73
- GetTwist
 - Joystick, 74
- GetValue
 - AnalogChannel, 14
 - AnalogModule, 20
- GetVoltage
 - AnalogChannel, 15
 - AnalogModule, 20
- GetWatchdog
 - RobotBase, 93
- GetX
 - Joystick, 74
- GetY
 - Joystick, 74
- GetZ
 - Joystick, 74
- Gyro, 59
 - ~Gyro, 60
 - GetAngle, 60
 - Gyro, 59
 - Reset, 60
 - SetSensitivity, 60
- HiTechnicCompass, 61
 - ~HiTechnicCompass, 61
 - GetAngle, 61
 - HiTechnicCompass, 61
- HolonomicDrive
 - RobotDrive, 99
- I2C, 63
 - ~I2C, 63
 - Broadcast, 63
 - Read, 63
 - VerifySensor, 64
 - Write, 64
- InitAccumulator
 - AnalogChannel, 15
- IsAccumulatorChannel
 - AnalogChannel, 15
- IsAlive
 - Watchdog, 128
- IsAutonomous
 - RobotBase, 93
- IsDisabled
 - RobotBase, 93
- IsNewDataAvailable
 - RobotBase, 93
- IsOperatorControl
 - RobotBase, 93
- IsPulsing
 - DigitalOutput, 43
- IsRangeValid
 - Ultrasonic, 124
- IsReady
 - Task, 118
- IsSuspended
 - Task, 118
- IsSystemActive
 - RobotBase, 93
 - Watchdog, 128
- IterativeRobot, 65
 - ~IterativeRobot, 66
 - AutonomousContinuous, 66
 - AutonomousInit, 66
 - AutonomousPeriodic, 66

- DisabledContinuous, 66
- DisabledInit, 66
- DisabledPeriodic, 67
- GetLoopsPerSec, 67
- IterativeRobot, 66
- RobotInit, 67
- SetPeriod, 67
- StartCompetition, 67
- TeleopContinuous, 67
- TeleopInit, 67
- TeleopPeriodic, 68
- Jaguar, 69
 - Get, 69
 - Jaguar, 69
 - Set, 69
- Joystick, 71
 - GetAxis, 72
 - GetAxisChannel, 72
 - GetBumper, 72
 - GetButton, 72
 - GetRawAxis, 72
 - GetRawButton, 73
 - GetThrottle, 73
 - GetTop, 73
 - GetTrigger, 73
 - GetTwist, 74
 - GetX, 74
 - GetY, 74
 - GetZ, 74
 - Joystick, 71
 - SetAxisChannel, 74
- kDefaultMinPwmHigh
 - PWM, 86
- kDefaultPwmPeriod
 - PWM, 86
- Kill
 - Watchdog, 128
- OperatorControl
 - SimpleRobot, 111
- ParticleAnalysisReport_struct, 76
- PCVideoServer, 77
- PIDController, 78
 - ~PIDController, 78
 - Disable, 79
 - Enable, 79
 - Get, 79
 - GetError, 79
 - GetSetpoint, 79
 - PIDController, 78
 - Reset, 79
 - SetContinuous, 79
 - SetInput, 79, 80
 - SetOutput, 80
 - SetSetpoint, 80
- PIDOutput, 81
- PIDSource, 82
- Ping
 - Ultrasonic, 124
- Printf
 - Dashboard, 39
 - SerialPort, 106
- Pulse
 - DigitalOutput, 43
- PWM, 83
 - ~PWM, 84
 - EnableDeadbandElimination, 84
 - GetPosition, 84
 - GetRaw, 84
 - GetSpeed, 85
 - kDefaultMinPwmHigh, 86
 - kDefaultPwmPeriod, 86
 - PWM, 84
 - SetBounds, 85
 - SetPeriodMultiplier, 85
 - SetPosition, 85
 - SetRaw, 86
 - SetSpeed, 86
- Read
 - I2C, 63
 - SerialPort, 106
- Relay, 88
 - ~Relay, 88
 - Relay, 88
 - Set, 89
- RequestInterrupts
 - AnalogTriggerOutput, 24
 - DigitalInput, 41
- Reset
 - Counter, 31
 - Encoder, 51
 - Gyro, 60
 - PIDController, 79
 - SerialPort, 107
 - Timer, 120
- ResetAccumulator
 - AnalogChannel, 15
- Resource, 90
 - ~Resource, 90
 - Allocate, 90
 - Free, 91
 - Resource, 90
- Restart
 - Task, 118

- Resume
 - Task, 118
- RobotBase, 92
 - ~RobotBase, 92
 - GetWatchdog, 93
 - IsAutonomous, 93
 - IsDisabled, 93
 - IsNewDataAvailable, 93
 - IsOperatorControl, 93
 - IsSystemActive, 93
 - RobotBase, 92
 - robotTask, 94
 - startRobotTask, 94
- RobotDeleter, 95
- RobotDrive, 96
 - ~RobotDrive, 97
 - ArcadeDrive, 98, 99
 - Drive, 99
 - HolonomicDrive, 99
 - RobotDrive, 96, 97
 - SetLeftRightMotorSpeeds, 99
 - TankDrive, 100
- RobotInit
 - IterativeRobot, 67
- RobotMain
 - SimpleRobot, 111
- robotTask
 - RobotBase, 94
- Scanf
 - SerialPort, 107
- ScopedSocket, 101
- SensorBase, 102
 - ~SensorBase, 102
 - AddToSingletonList, 103
 - CheckAnalogChannel, 103
 - CheckAnalogModule, 103
 - CheckDigitalChannel, 103
 - CheckDigitalModule, 103
 - CheckPWMChannel, 103
 - CheckPWMModule, 103
 - CheckRelayChannel, 103
 - CheckRelayModule, 103
 - CheckSolenoidChannel, 104
 - CheckSolenoidModule, 104
 - DeleteSingletons, 104
 - SensorBase, 102
 - SetDefaultAnalogModule, 104
 - SetDefaultDigitalModule, 104
 - SetDefaultSolenoidModule, 104
- SerialPort, 105
 - ~SerialPort, 105
 - DisableTermination, 106
 - EnableTermination, 106
 - Flush, 106
 - GetBytesReceived, 106
 - Printf, 106
 - Read, 106
 - Reset, 107
 - Scanf, 107
 - SerialPort, 105
 - SetFlowControl, 107
 - SetTimeout, 107
 - SetWriteBufferMode, 107
 - Write, 108
- Servo, 109
 - Get, 109
 - GetAngle, 110
 - Servo, 109
 - Set, 110
 - SetAngle, 110
- Set
 - DigitalOutput, 43
 - Jaguar, 69
 - Relay, 89
 - Servo, 110
 - Solenoid, 114
 - SpeedController, 115
 - Victor, 125
- SetAccumulatorCenter
 - AnalogChannel, 15
- SetAccumulatorDeadband
 - AnalogChannel, 15
- SetAccumulatorInitialValue
 - AnalogChannel, 15
- SetAngle
 - Servo, 110
- SetAutomaticMode
 - Ultrasonic, 124
- SetAverageBits
 - AnalogChannel, 16
 - AnalogModule, 20
- SetAxisChannel
 - Joystick, 74
- SetBounds
 - PWM, 85
- SetContinuous
 - PIDController, 79
- SetData
 - DriverStation, 48
- SetDefaultAnalogModule
 - SensorBase, 104
- SetDefaultDigitalModule
 - SensorBase, 104
- SetDefaultSolenoidModule
 - SensorBase, 104
- SetDigitalOut
 - DriverStation, 48

- SetDistancePerTick
 - Encoder, [51](#)
- SetDownSource
 - Counter, [31](#), [32](#)
- SetDownSourceEdge
 - Counter, [32](#)
- SetEnabled
 - Watchdog, [129](#)
- SetError
 - ErrorBase, [54](#)
- SetExpiration
 - Watchdog, [129](#)
- SetExternalDirectionMode
 - Counter, [32](#)
- SetFlowControl
 - SerialPort, [107](#)
- SetInput
 - PIDController, [79](#), [80](#)
- SetLeftRightMotorSpeeds
 - RobotDrive, [99](#)
- SetMaxPeriod
 - Counter, [32](#)
 - Encoder, [51](#)
- SetOutput
 - PIDController, [80](#)
- SetOversampleBits
 - AnalogChannel, [16](#)
 - AnalogModule, [21](#)
- SetPeriod
 - IterativeRobot, [67](#)
- SetPeriodMultiplier
 - PWM, [85](#)
- SetPosition
 - PWM, [85](#)
- SetPriority
 - Task, [118](#)
- SetPulseLengthMode
 - Counter, [32](#)
- SetRaw
 - PWM, [86](#)
- SetRelayValue
 - Compressor, [28](#)
- SetReverseDirection
 - Encoder, [52](#)
- SetSampleRate
 - AnalogModule, [21](#)
- SetSemiPeriodMode
 - Counter, [32](#)
- SetSensitivity
 - Accelerometer, [10](#)
 - Gyro, [60](#)
- SetSetpoint
 - PIDController, [80](#)
- SetSpeed
 - PWM, [86](#)
- SetTimeout
 - SerialPort, [107](#)
- SetUpdateWhenEmpty
 - Counter, [33](#)
- SetUpDownCounterMode
 - Counter, [33](#)
- SetUpSource
 - Counter, [33](#), [34](#)
- SetUpSourceEdge
 - Counter, [34](#)
- SetWriteBufferMode
 - SerialPort, [107](#)
- SetZero
 - Accelerometer, [10](#)
- SimpleRobot, [111](#)
 - Autonomous, [111](#)
 - OperatorControl, [111](#)
 - RobotMain, [111](#)
 - StartCompetition, [111](#)
- SlotToIndex
 - AnalogModule, [21](#)
 - Solenoid, [114](#)
- Solenoid, [113](#)
 - ~Solenoid, [113](#)
 - Get, [114](#)
 - Set, [114](#)
 - SlotToIndex, [114](#)
 - Solenoid, [113](#)
- SpeedController, [115](#)
 - Get, [115](#)
 - Set, [115](#)
- Start
 - Compressor, [28](#)
 - Counter, [34](#)
 - Encoder, [52](#)
 - Task, [119](#)
 - Timer, [120](#)
- StartCompetition
 - IterativeRobot, [67](#)
 - SimpleRobot, [111](#)
- startRobotTask
 - RobotBase, [94](#)
- StatusIsFatal
 - ErrorBase, [55](#)
- Stop
 - Compressor, [28](#)
 - Counter, [34](#)
 - Encoder, [52](#)
 - Task, [119](#)
 - Timer, [120](#)
- Suspend
 - Task, [119](#)
- Synchronized, [116](#)

- [~Synchronized, 116](#)
 - [Synchronized, 116](#)
- TankDrive
 - [RobotDrive, 100](#)
- Task, [117](#)
 - [GetID, 117](#)
 - [GetName, 117](#)
 - [GetPriority, 118](#)
 - [IsReady, 118](#)
 - [IsSuspended, 118](#)
 - [Restart, 118](#)
 - [Resume, 118](#)
 - [SetPriority, 118](#)
 - [Start, 119](#)
 - [Stop, 119](#)
 - [Suspend, 119](#)
 - [Task, 117](#)
 - [Verify, 119](#)
- TeleopContinuous
 - [IterativeRobot, 67](#)
- TeleopInit
 - [IterativeRobot, 67](#)
- TeleopPeriodic
 - [IterativeRobot, 68](#)
- Timer, [120](#)
 - [Get, 120](#)
 - [Reset, 120](#)
 - [Start, 120](#)
 - [Stop, 120](#)
 - [Timer, 120](#)
- Ultrasonic, [122](#)
 - [~Ultrasonic, 123](#)
 - [GetRangeInches, 123](#)
 - [GetRangeMM, 123](#)
 - [IsRangeValid, 124](#)
 - [Ping, 124](#)
 - [SetAutomaticMode, 124](#)
 - [Ultrasonic, 122, 123](#)
- Verify
 - [Task, 119](#)
- VerifySensor
 - [I2C, 64](#)
- Victor, [125](#)
 - [Get, 125](#)
 - [Set, 125](#)
 - [Victor, 125](#)
- VoltsToValue
 - [AnalogModule, 21](#)
- Watchdog, [127](#)
 - [~Watchdog, 127](#)
- Feed, [127](#)
- GetEnabled, [128](#)
- GetExpiration, [128](#)
- GetTimer, [128](#)
- IsAlive, [128](#)
- IsSystemActive, [128](#)
- Kill, [128](#)
- SetEnabled, [129](#)
- SetExpiration, [129](#)
- Watchdog, [127](#)
- Write
 - [I2C, 64](#)
 - [SerialPort, 108](#)